

Mitel RFP 12 Single Cell DECT

VOIP SYSTEM GUIDE

Release 1.0



NOTICE

The information contained in this document is believed to be accurate in all respects but is not warranted by Mitel Networks™ Corporation (MITEL®). The information is subject to change without notice and should not be construed in any way as a commitment by Mitel or any of its affiliates or subsidiaries. Mitel and its affiliates and subsidiaries assume no responsibility for any errors or omissions in this document. Revisions of this document or new editions of it may be issued to incorporate such changes.

No part of this document can be reproduced or transmitted in any form or by any means - electronic or mechanical - for any purpose without written permission from Mitel Networks Corporation.

TRADEMARKS

The trademarks, service marks, logos and graphics (collectively "Trademarks") appearing on Mitel's Internet sites or in its publications are registered and unregistered trademarks of Mitel Networks Corporation (MNC) or its subsidiaries (collectively "Mitel") or others. Use of the Trademarks is prohibited without the express consent from Mitel. Please contact our legal department at legal@mitel.com for additional information. For a list of the worldwide Mitel Networks Corporation registered trademarks, please refer to the website: <http://www.mitel.com/trademarks>.

VoIP System Guide
Release 1.0 - January

®,™ Trademark of Mitel Networks Corporation
© Copyright 2016 Mitel Networks Corporation
All rights reserved

| | |
|---|----|
| ABOUT THIS DOCUMENT | 7 |
| Audience..... | 7 |
| When Should I Read This Guide | 7 |
| Important Assumptions | 7 |
| COntents of this Guide | 2 |
| Abbreviations | 2 |
| References/Related Documentation..... | 3 |
| INTRODUCTION – SYSTEM OVERVIEW | 4 |
| Hardware Setup..... | 4 |
| Components of MITEL RFP 12 Single Cell DECT System..... | 4 |
| MITEL 112 DECT Phone | 4 |
| Base Station | 4 |
| Repeater | 4 |
| VoIP Administration Interface | 5 |
| Wireless Bands..... | 5 |
| System Capacity..... | 5 |
| MAKE HANDSET READY | 6 |
| Package Inspection | 6 |
| Contents | 6 |
| Before Using the Phone..... | 7 |
| Open Back Cover | 7 |
| Record Handset Serial Number (IPEI Number)..... | 8 |
| Install the Battery | 8 |
| Charge the Battery..... | 8 |
| Using the Handset | 9 |
| INSTALL BASE STATION/REPEATER | 9 |
| Package Inspection | 9 |
| Package Contents | 9 |
| Base Station Mechanics | 10 |
| Base Station – Reset Feature..... | 10 |
| Installing the Base Station | 10 |
| Determine IP Address of Base Station | 11 |

| | |
|---|-----------|
| CONFIGURE COMMUNICATIONS PLATFORM | 11 |
| Program MiVoice Business Phones | 11 |
| Configure a PRG with Call Handoff (Optional) | 12 |
| Configure for Suite Services (Optional) | 12 |
| MiVoice Office 250 SIP Phone Programming..... | 12 |
| Configure Dynamic Extension Express (Optional)..... | 13 |
| CONFIGURE VOIP SYSTEM | 13 |
| Login to VoIP System Administration Interface | 13 |
| Configure System Parameters..... | 15 |
| Add Handsets And Extensions | 21 |
| Register the Handsets | 23 |
| VOIP ADMINISTRATION INTERFACE | 26 |
| Web Navigation | 26 |
| Home/Status..... | 27 |
| Extensions | 29 |
| Add Extension..... | 29 |
| Group Call..... | 31 |
| Extensions List..... | 32 |
| Handset List..... | 33 |
| Edit Extension..... | 34 |
| Servers | 35 |
| Network..... | 39 |
| IP Settings | 39 |
| VLAN Settings | 40 |
| DHCP Options | 41 |
| NAT Settings..... | 41 |
| SIP/RTP Settings..... | 42 |
| Management Settings Definitions | 44 |
| Firmware Update Definitions | 48 |
| Time Server | 49 |
| Country | 52 |
| Security..... | 53 |
| Certificates..... | 53 |
| SIP Client Certificates..... | 54 |

| | |
|--|-----------|
| Password | 55 |
| Central Directory and LDAP | 55 |
| Local Central Directory | 55 |
| LDAP | 56 |
| Repeaters | 58 |
| Add Repeater..... | 58 |
| Register Repeater..... | 60 |
| Repeaters List..... | 60 |
| Statistics | 62 |
| System Data | 62 |
| Call Data | 63 |
| Repeater Data | 64 |
| DECT Data | 65 |
| Settings – Configuration File Setup | 65 |
| Sys Log..... | 67 |
| SIP Logs | 68 |
| FIRMWARE UPGRADES | 69 |
| Download Firmware Files | 69 |
| Upgrade the Firmware | 69 |
| Verification of Firmware Upgrade | 71 |
| FUNCTIONALITY OVERVIEW | 72 |
| Base Station Interfaces..... | 72 |
| Software Features | 73 |
| Call Features | 75 |
| APPENDIX A: BASIC NETWORK SERVER(S) CONFIGURATION | 78 |
| Server Setup..... | 78 |
| Requirements | 78 |
| DNS Server Installation/Setup | 78 |
| DHCP Server Setup..... | 79 |
| DHCP Server Troubleshooting | 79 |
| TFTP Server Setup..... | 81 |
| TFTP Server Settings | 81 |

APPENDIX B: USING BASE WITH VLAN NETWORK 83

- Introduction 83
- Backbone/ VLAN Aware Switches 84
- How VLAN Switch Work: VLAN Tagging 85
- Implementation Cases 85
- Base station Setup 86
- Configure Time Server 87
- VLAN Setup: Base Station 88

APPENDIX C: LOCAL CENTRAL DIRECTORY FILE HANDLING 89

- Central Directory Contact List Structure 89
- Central Directory Contact List Filename Format 90
- Import Contact List to Central Directory 90
- Central Directory using Server 91
- Verification of Contact List Import to Central Directory 93

ABOUT THIS DOCUMENT

This document describes the configuration, customization, management, operation, maintenance and trouble shooting of the Mitel RFP 12 Single Cell DECT system (Mitel 112 DECT handset, base station, and repeaters).

AUDIENCE

This guide is intended for

- networking professionals responsible for designing and implementing the wireless networks, and
- network administrators and IT support personnel that need to install, configure, maintain and monitor components of the system.

WHEN SHOULD I READ THIS GUIDE

Read this guide before you install the system components and when you are ready to setup or configure SIP server, NAT aware router, advanced VLAN settings, base stations, and multi-cell setup. This guide describes how to deploy a fully functionally system.

IMPORTANT ASSUMPTIONS

This document was written with the following assumptions:

1. You have understanding of network deployment in general.
2. You have working knowledge of basic TCP/IP/SIP protocols, Network Address Translation, and so forth.
3. A proper site survey has been performed, and the administrator has access to the plans.

CONTENTS OF THIS GUIDE

The contents of this document are summarized in the table below:

| SECTION | PURPOSE |
|---------------------------------------|---|
| System Overview | Describes the different elements in a typical VoIP Network |
| Make Handset Ready | Provides instructions on how to assemble handsets for use in the system |
| Install Base Station/Repeater | Provides instructions for installing base units and repeaters |
| Configure Communication Platform | Provides an overview of the configuration required on the MiVoice Business or MiVoice Office 250 platforms to support the handsets. |
| Configure VoIP System | Lists steps required to configure the system |
| VoIP Administration Interface | Describes the configuration interface and defines the parameters that are used to set up the system. |
| Firmware Upgrades | Provides the procedure of how to upgrade firmware to base stations and/or handsets and/or repeaters |
| Functionality Overview | Describes system functionality and features. |
| Basic Network Servers Configuration | Describes how to set up network servers. |
| VLAN Setup Management | Explains how to set up VLAN in the network |
| Local Central Directory File Handling | Describes the central directory file format and provides instructions on how to upload it. |

ABBREVIATIONS

For the purpose of this document, the following abbreviations apply:

| | |
|----------|---|
| DHCP: | Dynamic Host Configuration Protocol |
| DNS: | Domain Name Server |
| HTTP(S): | Hyper Text Transfer Protocol (Secure) |
| (T)FTP: | (Trivial) File Transfer Protocol |
| IOS: | Internetworking Operating System |
| IPEI | International Portable Equipment Identity |
| PCMA: | A-law Pulse Code Modulation |
| PCMU: | mu-law Pulse Code Modulation |
| PoE: | Power over Ethernet |

| | |
|--------|--|
| RTP: | Real-time Transport Protocol |
| RPORT: | Response Port (Refer to RFC3581 for details) |
| SIP: | Session Initiation Protocol |
| VLAN: | Virtual Local Access Network |
| TOS: | Type of Service (policy based routing) |
| URL: | Uniform Resource Locator |
| UA: | User Agent |

REFERENCES/RELATED DOCUMENTATION

[1]: **112 DECT Phone (Universal) and RFP 12 Single Cell Base Station Installation Guide (part number 57011091)**: provides instructions on how to make the required cable and power connections for the base station and charging cradle. It also provides instructions for installing the handset batteries.

[2]: **Mitel 112 DECT Phone (Universal) User Guide**: describes the features and functionalities provided by the Mitel 112 DECT Phone

[3]: **112 DECT Phone Quick Reference Guide for MiVoice Business**: provides instructions on how to use the features of the handset when it is connected to a MiVoice Business communications platform.

[4]: **112 DECT Phone Quick Reference Guide for MiVoice Office 250**: provides instructions on how to use the features of the handset when it is connected to a MiVoice Office 250 communications platform.

[5]: **MiVoice Business System Administration Help**: Refer to this online help system for instructions on how to program

- Mitel 112 DECT Phone as a “SIP generic device type” on the MiVoice Business system
- Mitel 112 DECT Phones into personal ring groups
- Support for Suite Services.

[6]: **MiVoice Office 250 Features and Programming Guide and Database Programming Online Help**: provides instructions on how to program the Mitel 112 DECT phone as a “SIP Phone” on the MiVoice Office 250.

INTRODUCTION – SYSTEM OVERVIEW

The MITEL RFP 12 Single Cell DECT system is a VoIP solution with support for up to 20 registered handsets and three repeaters.

HARDWARE SETUP

The base-stations are mounted on walls or poles so that each base-station is separated from each other by up to 10 meters (for indoor installation). Radio coverage can be extended using repeaters. Repeaters are range extenders only and cannot be used to increase local capacity.

The base-station antenna mechanism is based on a space diversity feature which improves coverage. The base-stations use the complete DECT MAC protocol layer and IP media stream audio encoding feature to provide up to five simultaneous calls.

COMPONENTS OF MITEL RFP 12 SINGLE CELL DECT SYSTEM

The system is made up of (but not limited to) the following components:

- Mitel 112 DECT Phone and charging cradle.
- Base station connected over an IP network and using DECT as air-core interface
- Repeater (optional)
- VoIP Administration Interface

MITEL 112 DECT PHONE

The phone is a lightweight, ergonomically and portable handset compatible with Wideband Audio (G.722), DECT, GAP standard, CAT-iq audio compliant.

The handset includes a color display with graphical user interface. It can also provide the subscriber with most of the features available for a wired phone, in addition to its roaming and handover capabilities.

BASE STATION

The Base Station converts IP protocol to DECT protocol and transmits the traffic to and from the wireless handsets over a channel. The base station has five available channels.

REPEATER

The base supports the IP DECT CAT-IQ repeater RTX4024. A repeater can be deployed to extend the range of a DECT handset. The repeater can also be utilized wherever there is a need to increase limited coverage or improve reception in remote areas.

The RYX4024 provides the following features:

- Up to three repeaters are supported per base station
- Wide band audio

- DECT encryption
- Automatic registration
- Maximum of three repeaters in daisy chain.

VOIP ADMINISTRATION INTERFACE

The VoIP Configuration Interface is a web based administration that you use

- configure the base station and relevant network end-nodes. For example, handsets can be registered or de-registered from the system using this interface.
- install software or firmware downloads onto base stations, repeaters and handsets.
- access system logs that can be used to troubleshoot the system.

WIRELESS BANDS

The bands supported in the VoIP are summarized as follows:

Frequency bands: 1880 – 1930 MHz (DECT)
1880 – 1900 MHz (10 carriers) Europe/ETSI
1910 – 1930 MHz (10 carriers) LATAM
1920 – 1930 MHz (5 carriers) US

SYSTEM CAPACITY

The network capacity of relevant components can be summarized as follows:

| DESCRIPTION | CAPACITY |
|---|----------|
| Single Cell Setup | 1 |
| Maximum number of repeaters per base station | 3 |
| Maximum number of handsets (SIP registrations) per base station | 20 |
| Single Cell Setup: Maximum number of simultaneous calls | 5 |
| Repeater: Max number of calls (narrow band) | 5 |
| Repeater: Maximum number of calls (G.722) | 2 |

Note: Each base station supports up to 20 handsets and three repeaters.

MAKE HANDSET READY

This section describes how to prepare the handset for use.

PACKAGE INSPECTION

Before you open the package, examine it for evidence of physical damage or mishandling. If the package appears damaged, report it to the relevant support centre of the regional representative or operator.


The following are the recommended procedure for you to use for inspection:

1. Examine all relevant components for damage.
2. If damage is detected, make a “defective on arrival – DOA” report to Mitel Customer Service. The Mitel Customer Service representative will initiate the necessary procedure to process the return. They will guide the network administrator on how to return the damaged package if necessary.
3. If no damage is found then unwrap all the components and dispose of empty package/carton(s) in accordance with country specific environmental regulations.

CONTENTS

Ensure that the following components were provided in the handset package before proceeding with the installation:


- 1 x handset and battery cover
- 2 AAA batteries
- 1 x charging cradle with wired A/C adapter



BEFORE USING THE PHONE

OPEN BACK COVER


1. Press down the back cover and slide it towards the bottom of the handset.
2. Remove back cover from handset.



RECORD HANDSET SERIAL NUMBER (IPEI NUMBER)

The International Portable Equipment Identity (IPEI) of each handset is printed either on a label located behind the battery or on the packaging label. Remove the handset back cover, take out the battery (if installed) and record the IPEI number.

You need this number to enable service to the handset. You must program it into the system database via the VoIP Administration interface.



INSTALL THE BATTERY

1. Never dispose of a battery in a fire; otherwise it will explode.
2. Never replace the batteries in potentially explosive environments, for example close to flammable liquids or gases.
3. ONLY use approved batteries and chargers from the vendor or operator.
4. Do not disassemble, customize, or short circuit the battery.

CHARGE THE BATTERY

Each handset is charged using a handset charger. The charger is a compact desktop unit that automatically maintains the correct battery charge levels and voltage.

The handset charger is powered by AC power adapter that supplies 5VDC at 1000mA. The AC power adapter is supplied from 110-240 VAC.

When charging the batteries for the first time, it is necessary to leave the handset in the charger for at least 10 hours before they are fully charged and the handset is ready for use.

For correct charging, ensure that the room temperature is between 0°C and 25°C (32°F and 77°F). Do not place the handset in direct sunlight.

The battery displayed in the top right of the screen indicates the charging status.

USING THE HANDSET

For instructions on how to use the handset features, refer to the Mitel 112 DECT Phone (Universal) User Guide available on the Mitel Customer Documentation site.

INSTALL BASE STATION/REPEATER

The following sections how to install the base station.


PACKAGE INSPECTION

Before you open the package, examine it for evidence of physical damage or mishandling. If the package appears damaged, report it to the relevant support centre of the regional representative or operator.

PACKAGE CONTENTS

Ensure that the following components were provided in the base unit package before proceeding with the installation:

- 2 x mounting screws and 2 x Anchors
- 1 x Category 5 cable (Ethernet cable)
- Base unit
- Power supply adapter



Back View of Base Station Unit

BASE STATION MECHANICS

The base station front panel has an LED indicator that signals the different functional states of the base unit and occasionally of the overall network. The indicator is off when the base unit is not powered. The table below summarizes the various LED states:

| LED STATE | STATUS |
|-----------------|---|
| OFF | No power |
| FLASHING GREEN | Initialization in progress |
| SOLID GREEN | Ethernet connection is available (Normal operation) |
| FLASHING ORANGE | No IP address |
| SOLID ORANGE | Reset required |
| FLASHING RED | Factory setting in progress OR Ethernet connection not available OR Handset registration/deregistration failed. |
| SOLID RED | Factory reset warning after a long press (10 seconds or more) of the Reset button OR Error condition. Replace base station if error condition persists. |

BASE STATION – RESET FEATURE

To reset the base station unit, press the small Reset button on the back of the unit. You can also reset the base station from the VoIP Administration Interface.

INSTALLING THE BASE STATION

1. Record the MAC address of the base station. The MAC address is listed on the bottom panel of the base.
2. Determine the best location that will provide an optimal coverage taking account the construction of the building, architecture, and building materials.
3. Mount the base station on a wall to cover a range of 50 meters (164 feet) for indoor installations or 300 meters (984 feet) for outdoor installations. We recommend the base station be mounted an angle on concrete, wood, or plaster pillars and walls for optimal radio coverage. Do not mount the base units upside down because it significantly reduces radio coverage.
4. Mount the base unit as high as possible to clear all nearby objects (for example: office cubicles and cabinets). If necessary, extend coverage to remote offices or halls with fewer telephony users by installing repeaters.
5. When you fasten the base stations to the pillar or wall, ensure that the screws do not touch the PC board in the unit. Secondly, avoid all contact with any high voltage lines.

DETERMINE IP ADDRESS OF BASE STATION

To identify the IP address of the base station:

1. On the handset press the round “Menu” button to access the main menu:



2. Dial *47*. “Searching” is displayed. Depending on the number of active base stations and the distance to the base it can take up to 5 minutes to find a base.
3. If there are multiple base stations available, use the down/up cursor to select the MAC address of the desired base. The base IP address is displayed.
4. Record the IP address.
5. Configure 112 DECT Phone on Communication Platform.

CONFIGURE COMMUNICATIONS PLATFORM

PROGRAM MIVOICE BUSINESS PHONES

Before you register the handset with the base station, complete the following MiVoice Business programming tasks. Refer to the MiVoice Business System Administration Tool online help for instructions:

1. License the Mitel 112 DECT Phone (handset) as a SIP device.
2. Program a user and handset extension in the “User and Services Configuration” form as a “Generic SIP Phone”.
3. Access the SIP Device Capabilities form. Program a SIP Device Capabilities index number using the standard defaults with the exception of the following options. In the SIP Device Capabilities form tabs, set the following options to **Yes**.
 - Replace System based with Device based In-Call Features
 - Enable Digit Collection In Busy Or Alerting State
 - Allow Display Updates
 - Enable Distinctive Ringing
 - Prevent the Use of IP Address 0.0.0.0 in SDP Messages.
4. Use the Search field in the “User and Device Configuration” form to locate the directory numbers that will be assigned to the handsets. Click the **Service Details** tab and assign the SIP Device Capabilities index number to each handset.

5. In the “Multiline Set Keys” form of the MiVoice Business System Administration tool, configure the handset with a second multi-call appearance of the prime line with the Ring Type set to “Ring”. Refer to the System Administration Tool online help for instructions.
6. You can optionally configure a
 - Mitel desktop phone and a handset in a Personal Ring Group, or
 - Mitel desktop phone and a handset for Suite Services (typically, used in a hospitality environment).

CONFIGURE A PRG WITH CALL HANDOFF (OPTIONAL)

Personal Ring Groups (PRGs) allow you to associate two or more devices for a single user under a common, prime directory number (DN). The devices ring simultaneously (Ring All) when the prime directory number is called. You can use PRGs to twin a person's desktop phone and his or her Mitel 112 DECT Phone together. The desk phone is considered the prime extension, which is referred to as the pilot number or prime member of the group. The cordless handset is programmed as a non-prime member of the group.

You can also program and label a **Handoff** key on the user's desk phone. Users can press the **Handoff** feature key to

- push a call that is in progress from their desktop phone to their Mitel 112 DECT Phone, or
- pull a call that is in progress from their Mitel 112 DECT Phone to their desktop phone.

The **Handoff** key is only supported on Mitel desktop phones. It is not supported on SIP devices and you cannot program it on a Mitel 112 DECT Phone.

Refer to the “Ring Groups Personal” and “Handoff (Personal Ring Groups)” topics in the “Features” book of the MiVoice Business System Administration Tool online help for programming instructions.

CONFIGURE FOR SUITE SERVICES (OPTIONAL)

Suite Service provides the ability to group a number of telephone lines through interconnected hotel/motel rooms, or suites, for the purposes of billing and shared telephone service. Refer to the following online book in the MiVoice Business System Administration Tool online help for a detailed description of Suite Services and programming instructions: System Applications > Hospitality > Suite Services.

MIVOICE OFFICE 250 SIP PHONE PROGRAMMING

Before you register a handset with base station, complete the following MiVoice Office 250 Database Programming tasks. Refer to the *MiVoice Office 250 Features and Programming Guide* and *Database Programming online help* for detailed instructions:

1. Ensure that you have a valid Category F license available for each handset that will be connected to the base station.
2. Program each handset as a “SIP Phone” (or part of a SIP Phone Group).

CONFIGURE DYNAMIC EXTENSION EXPRESS (OPTIONAL)

Dynamic Extension Express (DEE) allows you to associate two or more devices for a single user under a common main extension number. You can use DEE to “twin” a person's desktop phone and his or her handset together. The desk phone is considered the main extension, while the cordless handset is programmed as a secondary destination.

You can also program and label a DEE Handoff key (default feature code is 388) on the user's desk phone. Users can press the DEE Handoff feature key to push a call that is in progress from their desk phone to their handset.

For programming instructions, refer to the DEE topics in the latest *MiVoice Office 250 Features and Programming Guide* and *Database Programming Online Help*.

CONFIGURE VOIP SYSTEM

This section describes basic configuration of the system. See VoIP Administration Interface on page 26 for descriptions of the system parameter settings.

LOGIN TO VOIP SYSTEM ADMINISTRATION INTERFACE

1. Connect the base station to a private network via standard Ethernet cable (CAT-5).
2. Use the IP Search function on the handset to determine the IP address of the base station:
 - Press the center Menu button on the handset to access the main menu:



- Dial ***47***. “Searching” is displayed. Depending on the number of active base stations and the distance to the base it can take up to 5 minutes to find a base.
 - If multiple base stations are available, use the up/down Menu button to highlight the MAC address of the desired base. Press **Select**. The base IP address is displayed.
 - Record the IP address.
3. Open a standard internet browser (for example, FireFox)
 4. In the browser address bar enter `http://<IP Address of Base Station>`.
Username: **admin** (default)
Password: **admin** (default)
 5. Click **OK**.



6. The browser displays the Welcome page of the VoIP Administration interface. It lists the base station information.

| System Information: | |
|----------------------|---|
| Phone Type: | IPDECT |
| System Type: | Generic SIP (RFC 3261) |
| RF Band: | US |
| Current local time: | 25/Sep/2015 08:20:24 |
| Operation time: | 15 Days 19:35:08 (H:M:S) |
| RFPI Address: | 12770352; RPN:00 |
| MAC Address: | 00087b0ef4f9 |
| IP Address: | 10.35.83.24 |
| Firmware Version: | IPDECT/03.55/B0004/19-Aug-2015 15:39 |
| Firmware URL: | Firmware update server address: 10.36.161.126 |
| | Firmware path: |
| Base Station Status: | Idle |

| SIP Identity Status on this Base Station: | |
|---|------------|
| 71535@10.35.84.241 (p72) | Status: OK |
| 71340@10.35.84.241 (p72) | Status: OK |

CONFIGURE SYSTEM PARAMETERS

From the VoIP Administration interface, perform the following configuration:

1. Click **Servers**.
 - Enter the name of the MiVoice communications platform in the “Server Alias” field.
 - Enter the IP address of the MiVoice communications platform in the “Registrar” and “Outbound Proxy” fields.
 - Click **Save**.

Mitel SME VoIP

Servers

p72:
10.35.84.241

[Add Server](#)
[Remove Server](#)

Server Alias: p72

NAT Adaption: Enabled

Registrar: 10.35.84.241

Outbound Proxy: 10.35.84.241

Conference Server:

Call Log Server:

Reregistration time (s): 600

SIP Session Timers: Disabled

Session Timer Value (s): 1800

SIP Transport: UDP

Signal TCP Source Port: Enabled

Use One TCP Connection per SIP Extension: Disabled

Keep Alive: Enabled

Show Extension on Handset Idle Screen: Enabled

Hold Behaviour: RFC 3264

Attended Transfer Behaviour: Hold 2nd Call

Directed Call Pickup: Disabled

Directed Call Pickup Code:

Group Call Pickup: Disabled

Group Call Pickup Code:

Use Own Codec Priority: Disabled

2. Click **Network**:

- Set **DHCP/Static** field to “Static” (recommended).
- Enter the IP address of the base station.
- Enter the IP address of the Default Gateway (if required).
- Click **Save**.

Mitel SME VoIP

Network Settings

IP settings

DHCP/Static IP:

IP Address:

Subnet Mask:

Default Gateway:

DNS (Primary):

DNS (Secondary):

NAT Settings

Enable STUN:

STUN Server:

STUN Bindtime Determine:

STUN Bindtime Guard:

Enable RPORT:

Keep alive time:

VLAN Settings

ID:

User Priority:

DHCP Options

Plug-n-Play:

SIP/RTP Settings

Use Different SIP Ports:

RTP Collision Detection:

Always reboot on check-sync:

Local SIP port:

SIP ToS/QoS:

RTP port:

RTP port range:

RTP ToS/QoS:

3. Click **Management**.

- If you are deploying the handsets in a hospitality (Hotel/Motel) environment, enable Hotel Mode. Note that when this option is enabled, it changes default handset PIN from 0000 to 9351 and the PIN is required to access the **Settings** menu.
- Click **Save**.

Mitel SME VoIP

Management Settings

Base Station Name:

Settings

Management Transfer Protocol:

HTTP Management upload script:

User Name:

HTTP Management password:

Enable Automatic Prefix:

Set Maximum Digits of Internal Numbers:

Set Prefix for Outgoing Calls:

Hotel Mode:

Syslog/SIP Log

Upload of SIP Log:

SIP Log Server Address:

Syslog Level:

Syslog Server IP Address:

Syslog Server Port:

Configuration

Configuration Server Address:

Configuration File Download:

Base Specific File:

DHCP Controlled Config Server:

DHCP Custom Option:

DHCP Custom Option Type:

Save and Reboot Save Cancel Default Base Station

4. Click **Time**.
 - Set the system time.
 - Click **Save**.

Mitel SME VoIP

- Home/Status
- Extensions
- Servers
- Network
- Management
- Firmware Update
- Time**
- Country
- Security
- Central Directory
- Repeaters
- Statistics
- Configuration
- Syslog
- SIP Log
- Logout

Time Settings

| | |
|--------------------------------------|--|
| Time Server: | <input type="text" value="ca.pool.ntp.org"/> |
| Allow broadcast NTP: | <input checked="" type="checkbox"/> |
| Refresh time (h): | <input type="text" value="24"/> |
| Set timezone by country/region: | <input checked="" type="checkbox"/> |
| Timezone: | <input type="text" value="-5:00"/> |
| Set DST by country/region: | <input checked="" type="checkbox"/> |
| Daylight Saving Time (DST): | <input type="text" value="Automatic"/> |
| DST Fixed By Day: | <input type="text" value="Use Month and Day of Week"/> |
| DST Start Month: | <input type="text" value="March"/> |
| DST Start Date: | <input type="text" value="0"/> |
| DST Start Time: | <input type="text" value="2"/> |
| DST Start Day of Week: | <input type="text" value="Sunday"/> |
| DST Start Day of Week Last in Month: | <input type="text" value="Second First In Month"/> |
| DST Stop Month: | <input type="text" value="November"/> |
| DST Stop Date: | <input type="text" value="0"/> |
| DST Stop Time: | <input type="text" value="2"/> |
| DST Stop Day of Week: | <input type="text" value="Sunday"/> |
| DST Stop Day of Week Last in Month: | <input type="text" value="First In Month"/> |

5. Click **Country**.

- Set the country settings.
- Click **Save**.

Mitel SME VoIP

Country

Select country: US / Canada

State / Region: New York

Select Language: English

Set timezone by country/region:

Set DST by country/region:

Notes:

Save and Reboot Save Cancel

6. Click **Security**:

- Under **Password**, change the administrator password (default **admin**) used to access this interface.

CAUTION: Ensure that you record the new password. If you forget the administrator password, you must reset the base station to the default configuration values and reconfigure the system.

- Click **Save**.

Note: You can reset the stand to the default configuration values (including the username and password) using the RESET button on the base station. Press and hold the RESET button for greater than 10 seconds to reset the base station configuration to the default values.

Home/Status

Extensions

Servers

Network

Management

Firmware Update

Time

Country

Security

Central Directory

Repeaters

Statistics

Configuration

Syslog

SIP Log

Logout

Security

Certificates:

| Idx | Issued To | Issued To | Valid Until |
|----------------------------|-----------|-----------|-------------|
| <input type="checkbox"/> 0 | | | |
| <input type="checkbox"/> 1 | | | |
| <input type="checkbox"/> 2 | | | |
| <input type="checkbox"/> 3 | | | |

[Check All /Uncheck All](#)
With selected: [Delete Certificate\(s\)](#)

Import Trusted Certificates:
Filename:

Use Only Trusted Certificates:

SIP Client Certificates:

| Idx | Issued To | Issued To | Valid Until |
|----------------------------|-----------|-----------|-------------|
| <input type="checkbox"/> 0 | | | |
| <input type="checkbox"/> 1 | | | |

[Check All /Uncheck All](#)
With selected: [Delete Certificate\(s\)](#)

Import SIP Client Certificate and Key Pair:
Filename:

Password:

Username:

Current Password:

New Password:

Confirm Password:

ADD HANDSETS AND EXTENSIONS

1. Click **Extensions** and add the handsets.
 - Click **Handset**.
 - Click **Add Handset**.
 - Enter the IEPI of the handset. The IEPI is printed on a label located under the handset batteries.
 - Click **Save**.



The screenshot displays the Mitel SME VoIP web interface. On the left is a dark blue navigation sidebar with the following menu items: Home/Status, Extensions, Servers, Network, Management, Firmware Update, Time, Country, Security, and Central Directory. The main content area has a dark blue header with the Mitel logo and 'SME VoIP'. Below the header, the page title is 'Handset'. There is a text input field for 'IPEI:' containing the value '02:76:A7:B2:C4' and a small 'x' icon to clear the field. Below this is a label 'AC:' followed by a blank text input field. At the bottom of this section are two buttons: 'Save' and 'Cancel'. A horizontal separator line follows. Below the line is the section 'Import Local Phonebook:', which includes a 'Filename:' label, a text input field, and a 'Browse...' button. Below this is a 'Load' button. Another horizontal separator line follows. At the bottom is the section 'Export Local Phonebook:', which includes an 'Export' button.

2. Click **Extensions** and add the extensions.
 - Click **Add extension**
 - Enter the Extension number.
 - Enter the user's Display Name.
 - Select the Server (MiVoice communications platform).
 - Under **Select Handset(s)**, check the box to associate the extension with a handset.
 - Click **Save**.

Add extension

Extension:

Authentication User Name:

Authentication Password:

Display Name:

Mailbox Name:

Mailbox Number:

Server:

Call waiting feature:

BroadWorks Feature Event Package:

Forwarding Unconditional Number:

Forwarding No Answer Number:

Forwarding on Busy Number:

Select Handset(s)

| | Idx | IPEI |
|-------------------------------------|-------------|------------|
| <input type="checkbox"/> | Add Handset | N/A |
| <input checked="" type="checkbox"/> | 1 | 0276A7B2C4 |
| <input type="checkbox"/> | 2 | 0276A7B2CE |

REGISTER THE HANDSETS

1. Open base station to handset registration:
 - Click **Extensions**.
 - Optionally, change the AC (Access code). You enter the AC on the handset to initiate registration.
 - Check the boxes of the handsets that you want to register.
 - Click Register Handset(s).

Extensions and Handset

AC:

Local Call Groups:

Extensions / Handset

[Add Handset](#)
[Stop Registration](#)

| | Idx | IPEI | Handset State | Handset Type FW Info | FWU Progress | Extension |
|-------------------------------------|-----|------------|---------------|----------------------|--------------|-----------------------|
| <input checked="" type="checkbox"/> | 1 | 0276A7B2C4 | Present | 8430 355.4 | Complete | 71535 |
| <input type="checkbox"/> | 2 | 0276A7B2CE | Present | 8430 355.4 | Complete | 71340 |

[Check All / Uncheck All](#)

With selected: [Delete Handset\(s\)](#) [Register Handset\(s\)](#) [Deregister Handset\(s\)](#)

2. The parameters are saved.

The parameters are successfully saved

You will be redirected after 3 seconds


3. The base station is now open (in the ready state) for handset registration for the next 5 minutes. You must register the selected handsets with the base station using the following procedure in the next 5 minutes.

4. Next, register each handset with the base station. Start the registration procedure on the handset by following step “a” to “d” below.


a) Select main menu “Connectivity”




b) Select menu "Register"



c) Type in the “AC code” and press “OK” to start the registration. The default AC code is “0000”.



d) After a while the handset is registered, and the idle display is shown.



Note: The unique handset IPEI is displayed on sheet “Extensions” when the handset is successfully registered. The web page must be manually updated by pressing “F5” to see that the handset is registered; otherwise the handset IPEI (International Portable Equipment Identity) isn’t displayed on the web page.

- The following screen shows an example of the Extensions page after you have registered several handsets.

Extensions and Handset

AC:

Local Call Groups:

Extensions / Handset

[Add extension](#)

| | Idx | Extension | Display Name | Server | Server Alias | State | IPEI |
|--------------------------|-----|-----------------------|--------------|--------------|--------------|----------------|----------------------------|
| <input type="checkbox"/> | 1 | 71535 | Rita James | 10.35.84.241 | p72 | SIP Registered | 0276A7B2C4 |
| <input type="checkbox"/> | 2 | 71340 | Tim Eagles | 10.35.84.241 | p72 | SIP Registered | 0276A7B2CE |

[Check All Extensions /](#)
[Uncheck All Extensions](#)

With selected: [Start SIP Registration\(s\)](#) [SIP Delete Extension\(s\)](#)

- Initial system configuration is now complete.

Note: After you have configured the handsets on a base station, ensure that you have changed the administration interface username and password, and the handset AC codes from the default values to prevent unauthorized access.

VOIP ADMINISTRATION INTERFACE

You manage and troubleshoot the system through the VoIP Administration Interface. The interface is an HTTP Web Server service that resides in each base station.



Note: Enabling secure web is not possible. For secure configuration use secure provisioning.

This section defines the variables and parameters for configuration in the network.

WEB NAVIGATION

This section describes the left menu of the VoIP Administration Interface.

| WEB PAGE | DESCRIPTION |
|--------------------------|--|
| Home/Status | This "Welcome" page displays the system information and base station status. |
| Extensions | Manage the system handsets and extensions |
| Servers | Define which SIP/NAT server the network should connect to. |
| Network | <p>Configure the Network settings:</p> <p>NAT provisioning: allows configuration of features for resolving of the NAT – Network Address Translation. These features enable interoperability with most types of routers.</p> <p>DHCP: allows changes in protocol for getting a dynamic IP address.</p> <p>Virtual LAN: specifies the Virtual LAN ID and the User priority.</p> <p>IP Mode: specify either dynamic (DHCP) or static IP address for your network. Only complete the IP address if you using a static IP address, Otherwise, leave it blank.</p> <p>Subnet mask: Leave blank if using DHCP. Complete if assigning a static IP address.</p> <p>DNS server: Specify if using DHCP; otherwise, leave it blank. Enter the DNS server address of your Internet service provider. If you are using a static IP address the DNS = Dynamic Name Server.</p> <p>Default gateway: if using DHCP, leave it empty. Write in the IP address of your router, when you use static IP address.</p> |
| Management | Defines the Configuration server address, Management transfer protocol, and the sizes of logs/traces that should be catalogued in the system. |
| Firmware Update | Remote firmware updates (HTTP(s)/TFTP) settings of base stations and handsets. |
| Time | Configures a time server for the system. Use a time server that applies to the country of installation. The time server must deliver the time in Network Time Protocol (NTP). The base station and handsets clocks are synchronized to the time server. |
| Country | <p>Specify the country/territory where the network is located to ensure that your phone functions properly.</p> <p>Note: The base language and country setting are independent of each other.</p> |
| Security | Allows users to administrate certificates and create account credentials with which they can log in or log out of the embedded HTTP web server. |
| Central Directory | Interface to a common directory. You can import up to 3000 entries using *csv format file or configure a connection to an LDAP directory. |

| WEB PAGE | DESCRIPTION |
|----------------------|--|
| | Note: LDAP and central directory cannot operate at the same time. |
| Repeaters | Administration and configuration of repeaters of the system |
| Alarm | Administration and configuration of the alarm settings on the system. This controls the settings for alarms that can be sent to the handsets. This feature is only available on certain types of handsets. |
| Statistics | Overview of system and call statistics for a system. |
| Configuration | This shows detail and complete network settings for base station(s), HTTP/DNS/DHCP/TFTP server, SIP server, etc. |
| Syslog | Overall network related events or logs are displayed here (only live feed is shown). |
| SIP Log | SIP related logs can be retrieved from url link. It is also possible to clear logs from this feature. |

HOME/STATUS

This section describes the Home/Status page.

Mitel SME VoIP

Home/Status

Welcome

System Information:

| | |
|---------------------|---|
| Phone Type: | IPDECT |
| System Type: | Generic SIP (RFC 3261) |
| RF Band: | US |
| Current local time: | 25/Sep/2015 08:20:24 |
| Operation time: | 15 Days 19:35:08 (H:M:S) |
| RFPI Address: | 12770352; RPN:00 |
| MAC Address: | 00087b0ef4f9 |
| IP Address: | 10.35.83.24 |
| Firmware Version: | IPDECT/03.55/B0004/19-Aug-2015 15:39 |
| Firmware URL: | Firmware update server address: 10.36.161.126 |
| | Firmware path: |
| | Idle |

Base Station Status: Idle

SIP Identity Status on this Base Station:

| | |
|--|------------|
| 71535@10.35.84.241 (p72) | Status: OK |
| 71340@10.35.84.241 (p72) | Status: OK |

Press button to reboot.

Reboot Forced Reboot

Copyright © 2015, Mitel Networks Corporation

PARAMETER **DESCRIPTION**

| | |
|---|---|
| System information | This base current multi-cell state |
| Phone Type | Always IPDECT |
| System Type | This base customer configuration |
| RF Band | This base RF band setting |
| Current local time | This base local time |
| Operation time | Time from last boot of base |
| RFPI-Address | This base RFPI address |
| MAC-Address | This base MAC address |
| IP-Address | This base IP address |
| Firmware version | This base firmware version |
| Firmware URL | Firmware update server address and firmware path on server |
| Base Station Status | “Idle” : When no calls on base “In use” : When active calls on base |
| SIP Identity Status on this Base Station | List of extensions present at this base station. Format: “extension”@“this base IP address” followed by status to the right. Below is listed possible status: OK: Handset is registered SIP Error: SIP registration error |
| Reboot | Reboot after all connections is stopped on base. Connections are active call, directory access, firmware update active |
| Forced Reboot | Reboot immediately even active calls are ongoing. |

EXTENSIONS

This section describes the different parameters available whenever the administrator is creating extensions for handsets. Note, you cannot add extensions unless servers are defined. This section also describes the group call feature.

The system supports a maximum of 20 extensions with 20 associated handsets which can be divided between servers. Once 20 handsets are registered, it is not possible to add more extensions.



Note: Within servers or even with multi servers, extensions must always be unique. This means same extension number on server 1 cannot be re-used on server 2.

ADD EXTENSION

Mitel SME VoIP

- Home/Status
- Extensions
- Servers
- Network
- Management
- Firmware Update
- Time
- Country
- Security
- Central Directory
- Repeaters
- Statistics
- Configuration
- Syslog
- SIP Log
- Logout

Add extension

Extension:

Authentication User Name:

Authentication Password:

Display Name:

Mailbox Name:

Mailbox Number:

Server:

Call waiting feature:

BroadWorks Feature Event Package:

Forwarding Unconditional Number:

Forwarding No Answer Number: s

Forwarding on Busy Number:

Select Handset(s)

| | Idx | IPEI |
|--------------------------|-------------|------------|
| <input type="checkbox"/> | Add Handset | N/A |
| <input type="checkbox"/> | 1 | Q276A7B2C4 |
| <input type="checkbox"/> | 2 | Q276A7B2CE |

Copyright© 2015. Mitel Networks Corporation

| PARAMETER | DEFAULT VALUE(S) | DESCRIPTION |
|--|-------------------------|---|
| Extension | Empty | Handset phone number depending on the setup. Possible value(s): 8-bit string length Example: 1024 Note: The Extension must also be configured in SIP server in order for this feature to function. |
| Authentication User Name | Empty | Username: SIP authentication username Permitted value(s): 8-bit string length |
| Authentication Password | Empty | Password: SIP authentication password. Permitted value(s): 8-bit string length |
| Display Name | Empty | Name displayed on the handset for the extension Permitted value(s): 8-bit string length |
| Mailbox Name | Empty | Name of centralized system that is used to store phone voice messages that can be retrieved by recipient at a later time. Valid Input(s): 8-bit string Latin characters for the Name |
| Mailbox Number | Empty | Dialled mail box number by long key press on key 1. Valid Input(s): 0 – 9, *, # Note: Mailbox Number parameter is available only when it's enabled from SIP server. |
| Server | Server 1 IP | FQDN or IP address of SIP server. Drop down menu to select between the defined Servers of VoIP Service provider. |
| Call waiting feature | Enabled | Used to enable/disable Call Waiting feature. When disabled a second incoming call will be rejected. If enabled, a second call will be presented as call waiting. |
| Forwarding Unconditional Number | Empty Disabled | Number to which incoming calls must be re-routed, regardless of the current state of the handset. Forwarding Unconditional must be enabled to function. Note: Feature must be enabled in the SIP server before it can function in the network. Note: Feature will be automatically disabled in case the handset or extension is part of a group |
| Forwarding No Answer Number | Empty Disabled 90 | Number to which incoming calls must be re-routed to when there is no response from the SIP end node. Forwarding No Answer Number must be enabled to function. Note: Feature must be enabled in the SIP server before it can function in the network. Specify delay from call to forward in seconds. Note: Feature is automatically disabled if the handset or extension is part of a group. |
| Forwarding On Busy Number | Empty | Number to which incoming calls must be re-routed when SIP node is busy. Forwarding On Busy Number must be enabled to function. |

| PARAMETER | DEFAULT VALUE(S) | DESCRIPTION |
|-----------|------------------|--|
| | Disabled | Note: Feature must be enabled in the SIP server before it can function in the network Note: Feature is automatically disabled if the handset or extension is part of a group. |

GROUP CALL

When you add or edit an extension, you can subscribe handsets to the extension by selecting them in the **Selected Handset(s)** table, and make them part of a group.

Group Call is when a SIP extension is associated with multiple handsets. All handsets that are assigned with the extension can receive incoming calls and initiate outgoing calls from that extension. When assigned with Group Call, a handset supports all normal call features such as Hold, Transfer and so forth.

When an incoming call arrives to a group, all of the handsets assigned to the group are alerted. For example, if a group contains 20 handsets, all 20 handset will alert.

An alerting handset cannot receive another incoming call, and therefore if a handset subscribes for multiple Call Groups, and a call arrives for a 2nd Call Group while the handset is alerting, the handset will not receive this call. If DND is enabled for a given handset, it will not receive the incoming call.

For outgoing calls, it can be selected in the handset which line (i.e. Call Group) to use for the call. The maximum number of lines is 20. For any outgoing actions, the settings for the selected line (SIP extension) will be used.

EXTENSIONS LIST

The added extensions will be shown in the extension lists.

The list can be sorted by any of the top headlines, by mouse click on the headline link.

| PARAMETER | DESCRIPTION |
|--------------|---|
| Idx | Select / deselect for delete, register and deregister handsets |
| Extension | Given extension is displayed. |
| Display Name | Given display name is displayed. If no name given this field will be empty |
| Server | Server IP or URL |
| Server Alias | Given server alias is displayed. If no alias given this field will be empty. |
| State | SIP registration state – if empty the handset is not SIP registered. |
| IPEI | Handset IPEI. IPEI is a unique DECT identification number. Group call: One extension can be associated to up to 20 IPEI's. The IPEI's will be listed in this cell. |

HANDSET LIST

The added handsets will be shown in the handset lists.
The list can be sorted by any of the top headlines, by mouse click on the headline link.

| PARAMETER | DESCRIPTION |
|-----------|-------------|
|-----------|-------------|

| | |
|------------|--|
| Idx | Select / deselect for delete, register and deregister handsets |
|------------|--|

| | |
|-------------|--|
| IPEI | Handset IPEI. IPEI is unique DECT identification number. |
|-------------|--|

| | |
|----------------------|---|
| Handset state | <p>The state of the given handset:</p> <p>Present: The handset is DECT located at the base</p> <p>Detached: The handset is detached from the system (e.g. powered off)</p> <p>Removed: The handset has been out of sight for a specified amount of time (~one hour).</p> |
|----------------------|---|

| | |
|---------------------------------|--|
| Handset Type FW info | Handset type and firmware version of handset |
|---------------------------------|--|

| | |
|---------------------|---|
| FWU Progress | <p>Possible FWU progress states:</p> <p>Off: Means sw version is specified to 0 = fwu is off</p> <p>Initializing: Means FWU is starting and progress is 0%.</p> <p>X% : FWU ongoing</p> <p>Verifying X%: FWU writing is done and now verifying before swap</p> <p>"Waiting for charger" (HS) / "Conn. term. wait" (Repeater): All FWU is complete and is now waiting for handset/repeater restart.</p> <p>Complete HS/repeater: FWU complete</p> <p>Error: Not able to fwu e.g. file not found, file not valid etc</p> |
|---------------------|---|

| | |
|------------------|--|
| Extension | <p>Given extension is displayed.</p> <p>Group call: The cell will show all the extensions associated with this handset and IPEI.</p> |
|------------------|--|

Handset and extension list top/sub-menus

The handset extension list menu is used to control pairing or deletion of handset to the system (DECT registration/de-registrations) and to control SIP registration/de-registrations to the system.

Above and below the list are found commands for making operations on handsets/and extensions. The top menu is general operations, and the sub menu is always operating on selected handsets/extensions.

Screenshots

[Add extension](#)
[Stop Registration](#)
[Check All /Uncheck All](#)
With selected: [Delete Handset\(s\)](#) [Register Handset\(s\)](#) [Deregister Handset\(s\)](#)

In the below table each command is described.

| ACTIONS | DESCRIPTION |
|------------------------------|---|
| Add extension | Access to the "Add extension" sub menu |
| Stop Registration | Manually stop DECT registration mode of the system. This prevents any handset from registering to the system |
| Delete Handset(s) | Deregister selected handset(s), but do not delete the extension(s). |
| Register Handset(s) | Enable registration mode for the system making it possible to register at a specific extension (selected by checkbox) |
| Deregister Handset(s) | Deregister the selected handset(s) and delete the extension(s). |

EDIT EXTENSION

To edit extension use the mouse to click the link of the extension.

Edit extension will open the same configuration possibilities as add extension. Refer to the above add extension section.

SERVERS

In this section, we describe the different parameters available in the Servers configurations menu. A maximum of 10 servers can be configured.

Servers

p72:
10.35.84.241

[Add Server](#) [Remove Server](#)

Server Alias: p72

NAT Adaption: Enabled

Registrar: 10.35.84.241

Outbound Proxy: 10.35.84.241

Conference Server:

Call Log Server:

Reregistration time (s): 600

SIP Session Timers: Disabled

Session Timer Value (s): 1800

SIP Transport: UDP

Signal TCP Source Port: Enabled

Use One TCP Connection per SIP Extension: Disabled

Keep Alive: Enabled

Show Extension on Handset Idle Screen: Enabled

Hold Behaviour: RFC 3264

Attended Transfer Behaviour: Hold 2nd Call

Directed Call Pickup: Disabled

Directed Call Pickup Code:

Group Call Pickup: Disabled

Group Call Pickup Code:

Use Own Codec Priority: Disabled

DTMF Signalling: RFC 2833

DTMF Payload Type: 101

Remote Caller ID Source Priority: PAI - FROM

Codec Priority: G711U, G711A, G726, G729

RTP Packet Size: 20 ms

Secure RTP: Disabled

Secure RTP Auth: Disabled

SRTP Crypto Suites: AES_CM_128_HMAC_SHA1_32, AES_CM_128_HMAC_SHA1_80

Buttons: Save, Cancel, Reset Codecs, Remove, Reset Crypto Suites, Remove

Copyright © 2015. Mitel Networks Corporation

| PARAMETER | DEFAULT VALUE | DESCRIPTION |
|--------------|---------------|--|
| Server Alias | Empty | Parameter for server alias |
| NAT Adaption | Disabled | To ensure all SIP messages goes directly to the NAT gateway in the SIP aware router. |

| PARAMETER | DEFAULT VALUE | DESCRIPTION |
|---------------------------|---------------|---|
| Registrar | Empty | SIP Server proxy DNS or IP address Permitted value(s): AAA.BBB.CCC.DDD:<Port-Number> or <URL>:<Port-Number> Note: Specifying the Port Number is optional. |
| Outbound Proxy | Empty | This is a Session Border Controller DNS or IP address (OR SIP server outbound proxy address) Set the Outbound proxy to the address and port of private NAT gateway so that SIP messages sent via the NAT gateway. Permitted value(s): AAA.BBB.CCC.DDD or <URL> or <URL>:<Port-Number> Examples: "192.168.0.1", "192.168.0.1:5062", "nat.company.com" and "sip:nat@company.com:5065". |
| Conference Server | Empty | Broadsoft conference feature. Set the IP address of the conference server. In case an IP is specified pressing handset conference will establish a connection to the conference server. If the field is empty the original 3-party local conference of 8660 is used. |
| Call Log Server | Empty | Broadsoft call log feature. Set the IP address of the XSI call log server. In case an IP is specified pressing handset will use the call log server. If the field is empty the local call log is used |
| Re-registration time | 600 | The "expires" value 36nalyse36n in SIP REGISTER requests. This value indicates how long the current SIP registration is valid, and hence is specifies the maximum time between SIP registrations for the given SIP account. Permitted value(s): A value below 60 sec is not recommended, Maximum value 65636 |
| SIP Session Timers: | Disabled | RFC 4028. A "keep-alive" mechanism for calls. The session timer value specifies the maximum time between "keep-alive" or more correctly session refresh signals. If no session refresh is received when the timer expires the call will be terminated. Default value is 1800 s according to the RFC. Min: 90 s. Max: 65636. If disabled session timers will not be used. |
| Session Timer Values (s): | 1800 | Default value is 1800s according to the RFC. If disabled session timers will not be used. Permitted value(s): Minimum value 90, Maximum 65636 |
| SIP Transport | UDP | Select UDP, TCP, TLS 1.0 |
| Signal TCP Source Port | Disabled | When SIP Transport is set to TCP or TLS, a TCP (or TLS) connection will be established for each SIP |

| PARAMETER | DEFAULT VALUE | DESCRIPTION |
|---|---------------|---|
| | | extension. The source port of the connection will be chosen by the TCP stack, and hence the local SIP port parameter, specified within the SIP/RTP Settings (see 0) will not be used. The "Signal TCP Source Port" parameter specifies if the used source port shall be signaled explicitly in the SIP messages. |
| Use One TCP/TLS Connection per SIP Extension: | Disabled | <p>When using TCP or TLS as SIP transport, choose if a TCL/TLS connection shall be established for each SIP extension or if the base station shall establish one connection which all SIP extensions use. Please note that if TLS is used and SIP server requires client authentication (and requests a client certificate), this setting must be set to disabled.</p> <p>0: Disabled. (Use one TCP/TLS connection for all SIP extensions)</p> <p>1: Enabled. (Use one TCP/TLS connection per SIP extensions).</p> |
| Keep Alive | Enabled | This directive defines the window period (30 sec.) to keep opening the port of relevant NAT-aware router(s), etc. |
| Show Extension on Handset Idle Screen | Enabled | If enabled extension will be shown on handset idle screen. |
| Hold Behaviour | RFC 3264 | <p>Specify the hold behaviour by handset hold feature.</p> <p>RFC 3264: Hold is 37nalyse37n according to RFC 3264, i.e. the connection information part of the SDP contains the IP Address of the endpoint, and the direction attribute is sendonly, recvonly or inactive dependant of the context</p> <p>RFC 2543: The "old" way of 37nalyse37ng HOLD. The connection information part of the SDP is set to 0.0.0.0, and the direction attribute is sendonly, recvonly or inactive dependant of the context</p> |
| Attended Transfer Behaviour | Hold 2nd Call | <ol style="list-style-type: none"> 1. When we have two calls, and one call is on hold, it is possible to perform attended transfer. When the transfer soft key is pressed in this situation, we have traditionally also put the active call on hold before the SIP REFER request is sent. However, we have experienced that some PBXes do not expect that the 2nd call is put on hold, and therefore attended transfer fails on these PBXes. 2. The "Attended Transfer Behaviour" feature defines whether or not the 2nd call shall be put on hold before the REFER is sent. 3. If "Hold 2nd Call" is selected, the 2nd call will be held before REFER is sent. <p>If "Do Not Hold 2nd Call" is selected, the 2nd call will not be held before the REFER is sent</p> |
| Use Own Codec Priority | Disabled | <p>Default disabled.</p> <p>By enable the system codec priority during incoming</p> |

| PARAMETER | DEFAULT VALUE | DESCRIPTION |
|--------------------|--|--|
| | | call is used instead of the calling party priority. E.g. If base has G722 as top codec and the calling party has Alaw on top and G722 further down the list, the G722 will be chosen as codec for the call. |
| DTMF Signalling | RFC 2833 | Conversion of decimal digits (and '*' and '#') into sounds that share similar characteristics with voice to easily traverse networks designed for voice SIP INFO: Carries application level data along SIP signalling path (e.g.: Carries DTMF digits generated during SIP session OR sending of DTMF tones via data packets in the <u>same</u> internet layer as the Voice Stream, etc.). RFC 2833: DTMF handling for gateways, end systems and RTP trunks (e.g.: Sending DTMF tones via data packets in <u>different</u> internet layer as the voice stream) Both: Enables SIP INFO and RFC 2833 modes. |
| DTMF Payload Type | 101 | This feature enables the user to specify a value for the DTMF payload type / telephone event (RFC2833). |
| Codec Priority | G.711U G.711A G.726 | Defines the codec priority that base stations uses for audio compression and transmission. Possible Option(s): G.711U,G.711A, G.726, G.729, G.722. Note: Modifications of the codec list must be followed by a "reset codes" and "Reboot chain" on the multipage in order to change and update handsets. Note: With G.722 as first priority the number of simultaneous calls per base station will be reduced from 10 (8) to 4 calls. With G.722 in the list the codec negotiation algorithm is active causing the handset (phone) setup time to be slightly slower than if G.722 is removed from the list. With G.729 add on DSP module for the base is required. |
| RTP Packet size | 20ms | The packet size offered as preferred RTP packet size by 8630 when RTP packet size negotiation. Selections available: 20ms, 40ms, 60ms, 80ms |
| Secure RTP | Disabled | With enable RTP will be encrypted (AES-128) using the key negotiated via the SDP protocol at call setup. |
| Secure RTP Auth | Disabled | With enable secure RTP is using authentication of the RTP packages. Note: with enabled SRTP authentication maximum 4 concurrent calls is possible per base in a single or multicell system. |
| SRTP Crypto Suites | AES_CM_128_HMAX_SHA1_32 AES_CM_128_HMAX | Field list of supported SRTP Crypto Suites. The device is born with two suites. |

| PARAMETER | DEFAULT VALUE | DESCRIPTION |
|-----------|---------------|-------------|
| | _SHA1_80 | |



Note: Within servers or even with multi servers, extensions must always be unique. This means same extension number on server 1 cannot be re-used on server 2.

NETWORK

In this section, we describe the different parameters available in the network configurations menu.

IP SETTINGS

IP settings

DHCP/Static IP:

IP Address:

Subnet Mask:

Default Gateway:

DNS (Primary):

DNS (Secondary):

NAT Settings

Enable STUN:

STUN Server:

STUN Bindtime Determine:

STUN Bindtime Guard:

Enable RPORT:

Keep alive time:

| PARAMETER | DEFAULT VALUES | DESCRIPTION |
|------------------------|----------------|---|
| DHCP/Static IP | DHCP | If DHCP is enabled, the device automatically obtains TCP/IP parameters. Possible value(s): Static, DHCP DHCP: IP addresses are allocated automatically from a pool of leased address. Static IP: IP addresses are manually assigned by the network administrator. If the user chooses DHCP option, the other IP settings or options are not available. |
| IP Address | NA | 32-bit IP address of device (e.g. base station). 64-bit IP address will be supported in the future. Permitted value(s): AAA.BBB.CCC.DDD |
| Subnet Mask | NA | Is device subnet mask. Permitted value(s): AAA.BBB.CCC.DDD This is a 32-bit combination used to describe which portion an IP address refers to the subnet and which part refers to the host. A network mask helps users know which portion of the address identifies the network and which portion of the address identifies the node. |
| Default Gateway | NA | Device's default network router/gateway (32-bit). |

| PARAMETER | DEFAULT VALUES | DESCRIPTION |
|------------------------|----------------|---|
| | | <p>Permitted value(s): AAA.BBB.CCC.DDD e.g. 192.168.50.0 IP address of network router that acts as entrance to other network. This device provides a default route for TCP/IP hosts to use when communicating with other hosts on hosts networks.</p> |
| DNS (Primary) | NA | <p>Main server to which a device directs Domain Name System (DNS) queries.</p> <p>Permitted value(s): AAA.BBB.CCC.DDD or <URL> This is the IP address of server that contains mappings of DNS domain names to various data, e.g. IP address, etc. The user needs to specify this option when static IP address option is chosen.</p> |
| DNS (Secondary) | NA | This is an alternate DNS server. |

VLAN SETTINGS

Enable users to define devices (e.g. Base station, etc.) with different physical connection to communicate as if they are connected on a single network segment.

The VLAN settings can be used on a managed network with separate Virtual LANs (VLANs) for sending voice and data traffic. To work on these networks, the base stations can tag voice traffic it generates on a specific “voice VLAN” using the IEEE 802.1q specification.

VLAN Settings

ID:

User Priority:

| PARAMETER | DEFAULT VALUES | DESCRIPTION |
|---------------------------|----------------|--|
| VLAN id | 0 | <p>Is a 12 bit identification of the 802.1Q VLAN.</p> <p>Permitted value(s): 0 to 4094 (only decimal values are accepted) A VLAN ID of 0 is used to identify priority frames and ID of 4095 (i.e. FFF) is reserved. Null means no VLAN tagging or No VLAN discovery through DHCP.</p> |
| VLAN User Priority | 0 | <p>This is a 3 bit value that defines the user priority.</p> <p>Values are from 0 (best effort) to 7 (highest); 1 represents the lowest priority. These values can be used to prioritize different classes of traffic (voice, video, data, etc).</p> <p>Permitted value(s): 8 priority levels (i.e. 0 to 7)</p> |

For further help on VLAN configuration refer to Appendix.

DHCP OPTIONS

DHCP Options

Plug-n-Play:

Enabled

| PARAMETER | DEFAULT VALUES | DESCRIPTION |
|-------------|----------------|--|
| Plug-n-Play | Disabled | Enabled: DHCP option 43 to automatically provide PBX IP address to base. |

NAT SETTINGS

We define some options available when NAT aware routers are enabled in the network.

NAT Settings

Enable STUN:

Disabled

STUN Server:

STUN Bindtime Determine:

Enabled

STUN Bindtime Guard:

80

Enable RPORT:

Disabled

Keep alive time:

90

| PARAMETER | DEFAULT VALUES | DESCRIPTION |
|-------------------------|----------------|--|
| Enable STUN | Disabled | Enable to use STUN |
| STUN Server | NA | Permitted value(s): AAA.BBB.CCC.DDD (Currently only Ipv4 are supported) or url (e.g.: firmware.rtx.net). |
| STUN Bindtime Determine | Enabled | |
| STUN Bindtime Guard | 80 | Permitted values: Positive integer default is 90, unit is in seconds |
| Enable RPORT | Disabled | Enable to use RPORT in SIP messages. |
| Keep alive time | 90 | This defines the frequency of how keep-alive are sent to maintain NAT bindings. Permitted values: Positive integer default is 90, unit is in seconds |

SIP/RTP SETTINGS

These are some definitions of SIP/RTP settings:

SIP/RTP Settings

| | |
|------------------------------|------------|
| Use Different SIP Ports: | Disabled ▼ |
| RTP Collision Detection: | Enabled ▼ |
| Always reboot on check-sync: | Disabled ▼ |
| Local SIP port: | 5060 |
| SIP ToS/QoS: | 0x68 |
| RTP port: | 50004 |
| RTP port range: | 40 |
| RTP ToS/QoS: | 0xB8 |

| PARAMETER | DEFAULT VALUES | DESCRIPTION |
|--------------------------------|----------------|--|
| Use Different SIP Ports | Disabled | If disabled, the Local SIP port parameter specifies the source port used for SIP signalling in the system. If enabled, the Local SIP Port parameter specifies the source port used for first user agent (UA) instance. Succeeding UA's will get succeeding ports. |
| RTP Collision Detection | Enabled | |
| Local SIP port | 5060 | The source port used for SIP signalling Permitted values: Port number default 5060. |
| SIP ToS/QoS | 0x68 | Priority of call control signalling traffic based on both IP Layers of Type of Service (ToS) byte. ToS is referred to as Quality of Service (QoS) in packet based networks. Permitted values: Positive integer, default is 0x68 |
| RTP port | 50004 | The first RTP port to use for RTP audio streaming. Permitted values: Port number default 50004 (depending on the setup). |
| RTP port range | 40 | The number of ports that can be used for RTP audio streaming. Permitted values: Positive integers, default is 40 |
| RTP TOS/QoS | 0xB8 | Priority of RTP traffic based on the IP layer ToS (Type of Service) byte. ToS is referred to as Quality of Service (QoS) in packet based networks. See RFC 1349 for details. "cost bit" is not supported. <ul style="list-style-type: none"> o Bit 7..5 defines precedence. o Bit 4..2 defines Type of Service. |

| PARAMETER | DEFAULT VALUES | DESCRIPTION |
|-----------|----------------|--|
| | | <ul style="list-style-type: none">o Bit 1..0 are ignored. Setting all three of bit 4..2 will be ignored. Permitted values: Positive integer, default is 0xB8 |

MANAGEMENT SETTINGS DEFINITIONS

The administrator can configure base stations to perform some specific functions such as configuration of file transfers, firmware up/downgrades, password management, and SIP/debug logs.

Screenshot

Management Settings

Base Station Name:

Settings

Management Transfer Protocol:

HTTP Management upload script:

User Name:

HTTP Management password:

Enable Automatic Prefix:

Set Maximum Digits of Internal Numbers:

Set Prefix for Outgoing Calls:

Hotel Mode:

Syslog/SIP Log

Upload of SIP Log:

SIP Log Server Address:

Syslog Level:

Syslog Server IP Address:

Syslog Server Port:

Configuration

Configuration Server Address:

Configuration File Download:

Base Specific File:

DHCP Controlled Config Server:

DHCP Custom Option:

DHCP Custom Option Type:

Save and Reboot Save Cancel Default Base Station

| PARAMETER | DEFAULT VALUE | DESCRIPTION |
|--------------------------------------|---------------|--|
| Base Station Name: | VoIP | It indicates the title that appears at the top window of the browser and is used in the multicell page. |
| Management Transfer Protocol | TFTP | The protocol assigned for configuration file and central directory Valid Input(s): TFTP, HTTP, HTTPs |
| HTTP Management upload script | Empty | The folder location or directory path that contains the configuration files of the Configuration server. The configuration upload script is a file located in e.g. TFTP server or Apache Server which is also the configuration server. Permitted value(s): /<configuration-file-directory> Example: /CfgUpload Note: Must begin with (/) slash character. Either / or \ can |

| PARAMETER | DEFAULT VALUE | DESCRIPTION |
|---|---------------|--|
| | | be used. |
| HTTP Management password | Empty | Password that should be entered in order to have access to the configuration server. Permitted value(s): 8-bit string length |
| Enable Automatic Prefix | Disabled | |
| Set Maximum Digits of Internal Numbers | 0 | |
| Set Prefix for Outgoing Calls | Blank | |
| Hotel Mode | Disabled | For hospitality (Hotel/Motel) environments, enable the Hotel Mode setting to <ul style="list-style-type: none"> • Black out the handset display when placed in cradle (after 65 seconds) • Protect the handset Settings menu (changes default handset PIN from 0000 to 9351; PIN is required to access the Settings menu) • Enable silent upgrades and resets • Disable call logging • Prevent phonebook modification. |
| Configuration server address | Empty | Server/device that provides configuration file to base station. Type: DNS or IP address Permitted value(s): AAA.BBB.CCC.DDD or <URL> |
| Base Specific File | Empty | Base configuration file |
| Configuration File Download | Disabled | Base Specific file: Used when configuring a single cell base Multicell Specific File: Used when configuring a multicell based system Base and Multicell Specific File: Used on out of factory bases to specify VLAN and Multicell ID and settings. |
| DHCP Controlled Config Server | Disabled | Provisioning server options. DHCP Option 66: Look for provision file by TFTP boot up server. DHCP Custom Option: Look for provision file by custom option DHCP Custom Option & Option 66: Look for provision file by first custom option and then option 66. |
| DHCP Custom Option | Empty | By default option 160, but custom option can be defined. An option 160 URL defines the protocol and path information by using a fully qualified domain name for clients that can use DNS. |

| PARAMETER | DEFAULT VALUE | DESCRIPTION |
|-------------------------------|---------------|--|
| DHCP Custom Option Typr | Empty | URL: URL of server with path. Example of URL: http://myconfigs.com:5060/configs Default configuration file on server must follow the name: MAC.cfg IP Address: IP of server with path. |
| Text Messaging | Disabled | Disable/enable messaging with Mobicall server The third option is to "Enable Without Server". With this setting handset can send messages to other handsets, which support messaging. Note: Contact Mobicall to get the proper version and setup for Mobicall server |
| Text Messaging & Alarm server | Empty | Permitted value(s): AAA.BBB.CCC.DDD or <URL> |
| Text Messaging Port | 1300 | Port number of message server. |
| Text Messaging Keep Alive (m) | 30 | This defines the frequency of how keep-alive are sent Permitted values: Positive integer, unit is in minutes |
| Text Messaging Response (s) | 30 | This defines the frequency of how response timeout Permitted values: Positive integer, unit is in seconds |
| Text Messaging TTL | 0 | This defines the text messaging time to live Permitted values: Positive integer, unit is in seconds |
| SIP Log Server Address | Empty | Permitted value(s): AAA.BBB.CCC.DDD or <URL> Requires a predefined folder named: \SIP |
| Upload of SIP Log | Disabled | Enable this option to save low level SIP debug messages to the server. The SIP logs are saved in the file format: <MAC_Address><Time_Stamp>SIP.log |
| Syslog Server IP-Address | NA | Permitted value(s): AAA.BBB.CCC.DDD or <URL> |
| Syslog Server Port | NA | Port number of syslog server. |
| Syslog Level | Off | Off: No data is saved on syslog server Normal Operation: Normal operation events are logged, incoming call, outgoing calls, handset registration, DECT location, and call lost due to busy, critical system errors, general system information. System Analyze: Handset roaming, handset firmware updates status. The system 46nalyse level also contains the messages from normal operation. Debug: Used by Design for debug. Should not be enabled during normal operation. |
| Enable Automatic Prefix | Disabled | Disabled: Feature off. Enabled: The base will add the leading digit defined in "Set |

| PARAMETER | DEFAULT VALUE | DESCRIPTION |
|---|---------------|--|
| | | <p>Prefix for Outgoing Calls”.</p> <p>Enabled + fall through on * and #: Will enable detection of * or # at the first digit of a dialled number. In case of detection the base will not complete the dialled number with a leading 0.</p> <p>Examples:</p> <ol style="list-style-type: none"> 1. dialled number on handset * 1234 - > dialled number to the pabx *1234 2. dialled number on handset #1234 - > dialled number to the pabx #1234 3. dialled number on handset 1234 - > dialled number to the pabx 01234 |
| Set Maximum Digits of Internal Numbers | 0 | Used to detect internal numbers. In case of internal numbers no prefix number will be added to the dialled number. |
| Set Prefix for Outgoing Calls | Empty | Prefix number for the enabled automatic prefix feature. Permitted value(s): 1 to 9999 |

There are three ways of configuring the system.

1. Manual configuration by use of the Web server in the base station(s)
2. By use of configuration files that are uploaded from a disk via the “Configuration” page on the Web server.
3. By use of configuration files which the base station(s) download(s) from a configuration server.

For further details refer to doc reference [3].

FIRMWARE UPDATE DEFINITIONS

In this page, the system administrator can configure how base stations and SIP nodes upgrade/downgrade to the relevant firmware. Handset firmware update status can be found in the extensions/page and repeater firmware update status in the repeater page. Base firmware update status is found in the multicell page.

| PARAMETER | DEFAULT VALUE(S) | DESCRIPTION |
|---------------------------------------|------------------|--|
| Firmware update server address | Empty | IP address or DNS of firmware update files source Valid Inputs: AAA.BBB.CCC.DDD or <URL> Example: firmware.rtx.net or 10.10.104.41 |
| Firmware path | Empty | Location of firmware on server (or firmware update server path where firmware update files are located). Example: /East_Fwu Note: Must begin with (/) slash character |
| Required Version Type | Empty | Version of firmware to be upgraded (or downgraded) on handset type or repeater. Valid Input(s): 8-bit string length. E.g. 280 Note: Value version 0 will disable firmware upgrade for handsets and/or repeater Note: Two handset types will be serial firmware upgraded. First type 8630 then type 8430. |
| Required Version Base | Empty | Version of firmware to be upgraded (or downgraded) on Base station. Base units are referred to as gateways over here. Valid Input(s): 8-bit string length. E.g. 280 |

TIME SERVER

In this section, we describe the different parameters available in the Time Server menu.

The Time server supplies the time used for data synchronisation in a multi-cell configuration. As such it is mandatory for a multi-cell configuration. The system will not work without a time server configured.

As well the time server is used in the debug logs and for SIP traces information pages, and used to determine when to check for new configuration and firmware files.



Note: It is not necessary to set the time server for standalone base stations (optional).

Press the “Time PC” button to grab the current PC time and use in the time server fields.



Note: When time server parameters are modified/changed synchronisation between base stations can take up to 15 minutes before all base stations are synchronised, depending on the number of base stations in the system.

| PARAMETER | DEFAULT VALUES | DESCRIPTION |
|----------------------------|----------------|--|
| Time Server | Empty | DNS name or IP address of NTP server. Enter the IP/DNS address of the server that distributes reference clock information to its clients including Base stations, Handsets, etc. Valid Input(s): AAA.BBB.CCC.DDD or URL (e.g. time.server.com) Currently only Ipv4 address (32-bit) nomenclature is supported. |
| Allow broadcast NTP | Checked | |
| Refresh time (h) | Empty | The window time in hours within which time server refreshes. Valid Inputs: positive integer |

| PARAMETER | DEFAULT VALUES | DESCRIPTION |
|---|--------------------|--|
| Set timezone by country/region | Checked | By checked country setting is used (refer to country web page). |
| Time Zone | 0 | Refers to local time in GMT or UTC format. Min: -12:00 Max: +13:00 |
| Set DST by country/region | Checked | By checked country setting is used (refer to country web page). |
| Daylight Saving Time (DST) | Disabled | The system administrator can Enable or Disable DST manually. Automatic: Enter the start and stop dates if you select Automatic. |
| DST Fixed By Day | Use Month and Date | You determine when DST actually changes. Choose the relevant date or day of the week, etc. from the drop down menu. |
| DST Start Month | March | Month that DST begins Valid Input(s): Gregorian months (e.g. January, February, etc.) |
| DST Start Date | 25 | Numerical day of month DST comes to effect when DST is fixed to a specific date Valid Inputs: positive integer |
| DST Start Time | 3 | DST start time in the day Valid Inputs: positive integer |
| DST Start Day of Week | Monday | Day within the week DST begins |
| DST Start Day of Week, Last in Month | Last in Month | Specify the week that DST will actually start. |
| DST Stop Month | October | The month that DST actually stops. |
| DST Stop Date | 1 | The numerical day of month that DST turns off. Valid Inputs: positive integer (1 to 12) |
| DST Stop Time | 2 | The time of day DST stops Valid Inputs: positive integer (1 to 12) |
| DST Stop Day of Week | Sunday | The day of week DST stops |
| DST Stop Day of Week Last in Month | First in Month | The week within the month that DST will turn off. |

COUNTRY

The country setting controls the in-band tones used by the system. To select web interface language go to the management page.

| PARAMETER | DEFAULT VALUES | DESCRIPTION |
|---------------------------------------|----------------|---|
| Select Country | Germany | Supported countries: Australia, Belgium, Brasil, Denmark, Germany, Spain, France, Ireland, Italia, Luxembourg, Nederland, New Zealand, Norway, Portugal, Swiss, Finland, Sweden, Tyrkey, United Kingdom, US/Canada, Austria |
| State / Region | NA | Only shown by country selection US/Canada, Auustralia, Brasil |
| Select Language | English | Web interface language. Number of available languages: English, Dansk, Italiano, Tyrkie, Deutsch, Portuguese, Hrvatski, Srpski, Slovenian, Nederlands, Francaise, Espanol, Russian, Polski. |
| Set timezone by country/region | checked | When checked timezone will follow country/region |
| Set DST by country/region | checked | When checked DST will follow country/region |
| Notes | Empty | Only showing notes to time setting for countries: US/Canada, Brasil |



Note: By checked timezone and DST the parameters in web page Time will be discarded.

The following types of in-band tones are supported:

1. Dial tone
2. Busy tone
3. Ring Back tone
4. Call Waiting tone
5. Re-order tone

SECURITY

The security section is used for loading of certificates and for selecting if only trusted certificates are used. Furthermore, web password can be configured.

The Security web is divided into three sections: Certificates (trusted), SIP Client Certificates (and keys) and Password administration.

To setup secure fwu and configuration file download select HTTPs for the Management Transfer Protocol (refer to management web).

SIP and RTP security is server dependent and in order to configure user must use the web option Servers (refer to servers web).

CERTIFICATES

The certificates list contains the list of loaded certificates for the system. Using the left column check mark it is possible to check and delete certificates. To import a new certificate use the mouse “select file” and browse to the selected file. When file is selected, use the “Load” bottom to load the certificate.

The certificate format supported is DER encoded binary X.509 (.cer).

Security

Certificates:

| | Idx | Issued To | Issued To | Valid Until |
|--------------------------|-----|-----------|-----------|-------------|
| <input type="checkbox"/> | 0 | | | |
| <input type="checkbox"/> | 1 | | | |
| <input type="checkbox"/> | 2 | | | |
| <input type="checkbox"/> | 3 | | | |

[Check All /Uncheck All](#)

With selected: [Delete Certificate\(s\)](#)

Certificates list

| PARAMETER | DEFAULT VALUES | DESCRIPTION |
|------------------|----------------|---|
| Idx | Fixed indexes | Index number |
| Issued To | Empty | IP address – which is part of the certificate file |
| Issued To | Empty | Organization, Company – which is part of the certificate file |

PARAMETER DEFAULT VALUES DESCRIPTION

Valid Until Empty Date Time Year – which is part of the certificate file

Import Trusted Certificates:

Filename: No file selected.

Use Only Trusted Certificates:

By enabling Use Only Trusted Certificates, the certificates the base will receive from the server must be valid and loaded into the system. If no valid matching certificate is found during the TLS connection establishment, the connection will fail. When Use Only Trusted Certificates is disabled, all certificates received from the server will be accepted.



Note: It is important to use correct date and time of the system when using trusted certificates. In case of time/date not defined the certificate validation can fail.

SIP CLIENT CERTIFICATES

To be able to establish a TLS connection in scenarios, where the server requests a client certificate, a certificate/key pair must be loaded into the base. This is currently supported only for SIP.

To load a client certificate/key pair, both files must be selected at the same time, and it is done by pressing “select files” under “Import SIP Client Certificate and Key Pair” and then select the certificate file as well as the key file at the same time. Afterwards, press load.

The certificate must be provided as a DER encoded binary X.509 (.cer) file, and the key must be provided as a binary PKCS#8 file.



Note: Use Chrome for loading SIP Client Certificates.

SIP Client Certificates:

| | Idx | Issued To | Issued To | Valid Until |
|--------------------------|-----|-----------|-----------|-------------|
| <input type="checkbox"/> | 0 | | | |
| <input type="checkbox"/> | 1 | | | |

[Check All /Uncheck All](#)

With selected: [Delete Certificate\(s\)](#)

Import SIP Client Certificate and Key Pair:

Filename: No files selected.

PASSWORD

In the below the password parameters are defined.

Password:

Username:

Current Password:

New Password:

Confirm Password:

| PARAMETER | DEFAULT VALUES | DESCRIPTION |
|-------------------------|----------------|--|
| Username | Admin | Can be modified to any supported character and number |
| Current Password | Admin | Can be modified to any supported character and number |
| New Password | Empty | Change to new password |
| Confirm Password | Empty | Confirm password to reduce accidentally wrong changes of passwords |

Password valid special signs: @/|<>-_.:!*+##

Password valid numbers: 0-9

Password valid letters: a-z and A-Z

CENTRAL DIRECTORY AND LDAP

The system supports two types of central directories, a local central directory or LDAP directory.

For both directories caller id look up is made with match for 6 digits of the phone number.

LOCAL CENTRAL DIRECTORY

Select local and save for local central directory.

Screenshot

| PARAMETER | DEFAULT VALUES | DESCRIPTION |
|--------------|----------------|---|
| Local | Local | Drop down menu to select between local central directory and LDAP based central directory |

| | | |
|--------------------------------------|-------|---|
| Server | Empty | The parameter is used if directory file is located on server. Valid Inputs: AAA.BBB.CCC.DDD or <URL> Refer to appendix for further details. |
| Filename | Empty | The parameter is used if directory file is located on server. Refer to appendix for further details |
| Phonebook reload interval (s) | 0 | The parameter is controlling the reload interface of phonebook in seconds. The feature is for automatic reload the base phonebook file from the server with intervals. It is recommended to specify a conservative value to avoid overload of the base station. With default value setting 0 the reload feature is disabled. |

Import Central Directory

The import central directory feature is using a browse file approach. After file selection press the load button to load the file. The system support only the original *.csv format. Please note that some excel csv formats are not the original csv format. The central directory feature can handle up to 3000 contacts. For further details of the central directory feature refer to appendix.

LDAP

In the Location field, select LDAP Server and click Save.

| PARAMETER | DEFAULT VALUES | DESCRIPTION |
|--------------------|----------------|---|
| LDAP Server | LDAP Server | Drop down menu to select between local central directory and LDAP based central directory. LDAP Server is displayed when LDAP server is selected. |
| Server | Empty | IP address of the LDAP server. Valid Inputs: AAA.BBB.CCC.DDD or <URL> |
| Port | Empty | The server port number that is open for LDAP connections. |
| Sbase | Empty | Search Base. The criteria depends on the configuration of the LDAP server. Example of the setting is CN=Users, DC=umber, DC=loc |
| LDAP filter | Empty | LDAP Filter is used to as a search filter, e.g. setting LDAP filter to ((givenName=%*)(sn=%*)) the IP-DECT will use this filter when requesting entries from the LDAP server. % will be replaced with the entered prefix e.g searching on J will give the filter ((givenName=J*)(sn=J*)) resulting in a search for given name starting with a J or surname starting with J. |
| Bind | Empty | Bind is the username that will be used when the IP-DECT phone connects to the server |
| Password | Empty | Password is the password for the LDAP Server |
| Name | Empty | The name can be used to specify if sn+givenName or cn (common name) is return in the LDAP search results |
| Work Number | Empty | Work number is used to specify that LDAP attribute that will be mapped to the handset work number |

| PARAMETER | DEFAULT VALUES | DESCRIPTION |
|---------------|----------------|---|
| Home Number | Empty | Home number is used to specify that LDAP attribute that will be mapped to the handset home number |
| Mobile Number | Empty | Mobile number is used to specify that LDAP attribute that will be mapped to the handset mobile number |

REPEATERS

Within this section we describe the repeater parameter, and how to operate the repeater.

ADD REPEATER

From repeaters web select “Add Repeater”

Screenshot

The screenshot shows the 'Repeaters' management page. At the top, there are links for 'Add Repeater', 'Refresh', and 'Stop Registration'. Below these is a table with the following columns: Idx, RPN, Name/IPEI, DECT sync source, DECT sync mode, State, FW Info, and FWU Progress. The table contains three entries:

| Idx | RPN | Name/IPEI | DECT sync source | DECT sync mode | State | FW Info | FWU Progress |
|----------------------------|-------|----------------------------|------------------|----------------|---------------|---------|--------------|
| <input type="checkbox"/> 0 | RPN01 | Office A100/ 005AD85FB0 | RPN00 (-26dBm) | Manually | Present@RPN00 | 39 | Off |
| <input type="checkbox"/> 1 | RPN02 | Office B120/ 005AD85D90 | RPN01 (-34dBm) | Manually | Present@RPN00 | 39 | Off |
| <input type="checkbox"/> 2 | RPN03 | Office D130/ 015AD85E80 | RPN02 (-34dBm) | Manually | Present@RPN00 | 39 | Off |

Below the table, there are links for 'Check All / Uncheck All' and a note: 'With selected: Delete Repeater(s), Register Repeater(s), Deregister Repeater(s)'.

Then select “DECT Sync mode”

Screenshot

The screenshot shows the 'Repeater' configuration form. It includes a 'Name' text input field, a 'DECT sync mode' dropdown menu currently set to 'Manually', and a 'Save' button. Below this is a section with two dropdown menus: 'RPN' (set to 'RPN01') and 'DECT sync source' (set to 'RPN00 (-∞dBm) (RTX Chain Canteen1 - static IP)').


PARAMETERS DESCRIPTION

| | |
|-----------------------|---|
| Name | Repeater name. If no name specified the field will be empty |
| DECT sync mode | <p>Manually: User controlled by manually assign “Repeater RPN” and “DECT sync source RPN”</p> <p>Local Automatical: Repeater controlled by auto detects best base signal and auto assign RPN.</p> |

Manually

User controlled by manually assign “Repeater RPN” and “DECT sync source RPN”. The parameters are selected from the drop down menu.

Screenshot



| PARAMETERS | DESCRIPTION |
|------------------|---|
| Idx | System counter |
| RPN | <p>SINGLE CELL SYSTEM: The base has always RPN00, first repeater will then be RPN01, second repeater RPN02 and third RPN03 (3 repeaters maximum per base)</p> <p>MULTI CELL SYSTEM: Bases are increment by 2^2 in hex, means first base RPN00 second base RPN04 etc., in between RPN01, 02, 03 addressed for repeaters at Primary base and 05, 06, 07 addressed for Secondary base (3 repeaters maximum per base)</p> |
| DECT sync source | Select the base or repeater the repeater has to be synchronized to. |

Local Automatical

Repeater controlled by auto detects best base signal and auto assign RPN. The RPN and DECT sync source are greyed out.

Repeater

Name:

DECT sync mode:

| RPN | DECT sync source |
|------------------------------------|---|
| <input type="text" value="ERROR"/> | <input type="text" value="RPN00 (-∞dBm) (RTX Chain Canteen1 - static IP)"/> |

The repeater RPN is dynamic assigned in base RPN range.

With local automatical mode, repeater on repeater (chain) is not supported.

REGISTER REPEATER

Adding a repeater makes it possible to register the repeater. Registration is made by select the repeater and pressing register repeater. The base window for repeater registration will be open until the registration is stopped. By stopping the registration all registration on the system will be stopped inclusive handset registration.

| Idx | RPN | IPEI | DECT sync source | DECT sync mode | State | FW Info | FWU Progress |
|-------------------------------------|----------|-------|------------------|----------------|-------------------|---------|--------------|
| <input checked="" type="checkbox"/> | <u>0</u> | RPN01 | FF:FF:FF:FF:FF | RPN00 (-∞dBm) | Local Automatical | | |

[Check All / Uncheck All](#)
 With selected: [Delete Repeater\(s\)](#) [Register Repeater\(s\)](#) [Deregister Repeater\(s\)](#)

REPEATERS LIST

Repeaters

[Add Repeater](#)

[Refresh](#)
[Stop Registration](#)

| Idx | RPN | Name/ IPEI | DECT sync source | DECT sync mode | State | FW Info | FWU Progress |
|--------------------------|----------|----------------------------|------------------|----------------|---------------|---------|--------------|
| <input type="checkbox"/> | <u>0</u> | Office A100/ 005AD85FB0 | RPN00 (-26dBm) | Manually | Present@RPN00 | 39 | Off |
| <input type="checkbox"/> | <u>1</u> | Office B120/ 005AD85D90 | RPN01 (-34dBm) | Manually | Present@RPN00 | 39 | Off |
| <input type="checkbox"/> | <u>2</u> | Office D130/ 015AD85E80 | RPN02 (-34dBm) | Manually | Present@RPN00 | 39 | Off |

[Check All / Uncheck All](#)
 With selected: [Delete Repeater\(s\)](#) [Register Repeater\(s\)](#) [Deregister Repeater\(s\)](#)

| PARAMETERS | DESCRIPTION |
|-------------------------|--|
| IDx | Repeater unit identity in the chained network. Permitted Output: Positive Integers |
| RPN | The Radio Fixed Part Number is an 8-bit DECT cell identity allocated by the installer. The allocated RPN within the must be geographically unique. Permitted Output: 0 to 255 (DEC) OR 0x00 to 0xFF (HEX) |
| Name/IPEI | Contains the name and the unique DECT serial number of the repeater. If name is given the field will be empty. |
| DECT sync Source | The "multi cell chain" connection to the specific Base/repeater unit. Maximum number of chain levels is 12. Sync. source format: "RPNyy (-zz dBm)" yy: RPN of source zz: RSSI level seen from the actual repeater |
| DECT sync Mode | Manually: User controlled by manually assign "Repeater RPN" and "DECT sync source RPN" Local Automatical: Repeater controlled by auto detects best base signal and auto assign RPN. Chaining Automatical: Base controlled by auto detects best base or repeater signal and auto assign RPN. This feature will be supported in a future version |
| State | Present@unit means connected to unit with RPN yy |
| FW info | Firmware version |
| FWU Progress | Possible FWU progress states: Off: Means sw version is specified to 0 = fwu is off Initializing: Means FWU is starting and progress is 0%. X% : FWU ongoing Verifying X%: FWU writing is done and now verifying before swap "Conn. term. wait" (Repeater): All FWU is complete and is now waiting for connections to stop before repeater restart. Complete HS/repeater: FWU complete Error: Not able to fwu e.g. file not found, file not valid etc |

STATISTICS

The statistic feature is divided into four administrative web pages, which can be access from any base.

1. System
2. Calls
3. Repeater
4. DECT data

All four views have an embedded export function, which export all data to comma separated file.

By pressing the clear button all data in the full system is cleared.

SYSTEM DATA

The system data web is access by <http://ip/SystemStatistics.html> and data is organized in a table as shown in below example.

Screenshot

The screenshot shows a web interface titled "Statistics". At the top, there are two buttons: "Export" and "Clear". Below the buttons, there are four navigation links: "System", "Calls", "Repeater", and "DECT". The main content is a table with the following structure:

| Base Station Name | Operation/Duration D-H:M:S | Busy | Busy Duration D-H:M:S | SIP Failed | Handset Removed | Searching | Free Running | DECT Source Changed |
|-------------------|-------------------------------|------|--------------------------|------------|-----------------|-----------|--------------|---------------------|
| Sum | 0-00:08:39/ 6-22:34:28 | 0 | | 0 | 0 | 0 | 0 | 0 |

The table is organized with headline row, data pr. base rows and with last row containing the sum of all base parameters.

| PARAMETERS | DESCRIPTION |
|-------------------|---|
| Base Station Name | Base IP address and base station name from management settings |
| Operation time | Total operation time for the base |
| Busy Count | Busy Count is the number of times the base has been busy. |
| Busy Duration | Busy duration is the total time a base has been busy for speech (8 or more calls active). |
| SIP Failed | Failed SIP registrations count the number of times a SIP registration has failed |

| | |
|---------------------|--|
| Handset Removed | Handset removed count is the number of times a handset has been marked as removed |
| Searching | Base searching is the number of times a base has been searching for it's sync source |
| Free Running | Base free running is the number of times a base has been free running |
| DECT Source Changed | Number of time a base has changed sync source |

CALL DATA

The call data web is access by <http://ip/CallStatistics.html> and data are organized in a table as shown in below example.

Screenshot

System / Calls / Repeater / DECT

| Base Station Name | Operation / Duration D-H:M:S | Count | Dropped | No Response | Duration D-H:M:S | Active | Max Active | Codec G711U: G711A: G729: G722: G726: | Handover Success | Handover Failed |
|-------------------|---------------------------------|-------|---------|-------------|---------------------|--------|------------|--|---------------------|--------------------|
| Sum | 0-00:14:12/ 6-22:40:01 | 7 | 0 | 0 | 0-00:00:31 | 0 | 2 | 0:0:0:3:0 | 0 | 0 |

The table is organized with headline row, data pr. base rows and with last row containing the sum of all base parameters.

PARAMETERS DESCRIPTION

| | |
|-------------------------|---|
| Base Station Name | Base IP address and base station name from management settings |
| Operation time/Duration | Total operation time for the base since last reboot or reset Duration is the time from data was cleared or system has been firmware upgraded. |
| Count | Counts number of calls on a base. |
| Dropped | Dropped calls are the number of active calls that was dropped. E.g. if a user has an active call and walks out of range, the calls will be counted as a dropped call. An entry is stored in the syslog when a call is dropped. |
| No response | No response calls is the number of calls that have no response, e.g. if a external user tries to make a call to a handset that is out of range the call is counted as no response. An entry is stored in the syslog when a call is no response. |
| Duration | Call duration is total time that calls are active on the base. |
| Active | Active call shows how many active calls that are active on the base (Not active DECT calls, but active calls). On one base there can be up to 30 active calls. |
| Max Active | Maximum active calls are the maximum number of calls that has been active at the same time. |

| PARAMETERS | DESCRIPTION |
|------------------|---|
| Codecs | Logging and count of used codec types on each call. |
| Handover Success | Counts the number of successful handovers. |
| Handover Failed | Counts the number of failed handovers. |

REPEATER DATA

Statistics

[System](#) / [Calls](#) / **[Repeater](#)** / [DECT](#)

| Idx/Name | Operation D-H:M:S | Busy | Busy Duration D-H:M:S | Max Active | Searching | Recovery | DECT Source Changed | Wide Band | Narrow Band |
|-------------------|--|------|-----------------------|------------|-----------|----------|---------------------|-----------|-------------|
| 0/ Office A100 | 7-23:17:43 | 38 | 0-00:13:13 | 12 | 1 | 0 | 0 | 0 | 225 |
| 1/ Office B120 | 7-23:18:08 | 21 | 0-00:11:01 | 10 | 1 | 1 | 0 | 0 | 137 |
| 2/ Office D130 | 2-20:48:49 | 13 | 0-00:10:27 | 10 | 1 | 1 | 0 | 0 | 58 |
| Sum | Max 7-23:18:08 Min 2-20:48:49 | 72 | 0-00:34:41 | 32 | 3 | 2 | 0 | 0 | 420 |

The table is organized with headline row, data pr. base rows and with last row containing the sum of all base parameters.

| PARAMETERS | DESCRIPTION |
|-------------------------|--|
| Idx | Base IP address and base station name from management settings |
| Operation time/Duration | Total operation time for the repeater since last reboot or reset Duration is the time from data was cleared or system has been firmware upgraded. |
| Busy | Busy Count is the number of times the repeater has been busy. |
| Busy Duration | Busy duration is the total time a repeater has been busy for speech (5 or more calls active). |
| Max Active | Maximum active calls are the maximum number of calls that has been active at the same time. |
| Searching | Repeater searching is the number of times a repeater has been searching for it's sync source |
| Recovery | In case the sync source is not present anymore the repeater will go into lock on another base or repeater and show recovery mode |

DECT Source Changed Number of time a repeater has changed sync source

Wide Band Number of wideband calls on repeaters

Narrow Band Number of narrow band calls on repeaters

DECT DATA

The DECT data web is access by <http://ip/DectStatistics.html> and data is organized in a table as shown in below example.

Screenshot

The screenshot shows a web interface titled "Statistics" with "Export" and "Clear" buttons. Below the buttons is a breadcrumb trail: "System / Calls / DECT". The main content is a table with 13 columns (Frequency and Slot0-Slot11) and 10 rows (Frequency0-Frequency9).

| | Slot0 | Slot1 | Slot2 | Slot3 | Slot4 | Slot5 | Slot6 | Slot7 | Slot8 | Slot9 | Slot10 | Slot11 |
|------------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|--------|--------|
| Frequency0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Frequency1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Frequency2 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Frequency3 | 2 | 3 | 2 | 9 | 4 | 3 | 2 | 3 | 9 | 5 | 3 | 4 |
| Frequency4 | 4 | 7 | 5 | 1 | 5 | 3 | 3 | 6 | 4 | 3 | 4 | 4 |
| Frequency5 | 6 | 0 | 2 | 2 | 1 | 5 | 5 | 2 | 4 | 3 | 5 | 6 |
| Frequency6 | 3 | 3 | 7 | 3 | 4 | 3 | 4 | 5 | 4 | 4 | 3 | 2 |
| Frequency7 | 5 | 2 | 4 | 3 | 4 | 4 | 2 | 4 | 1 | 5 | 3 | 3 |
| Frequency8 | 3 | 1 | 3 | 2 | 2 | 1 | 4 | 2 | 3 | 2 | 2 | 1 |
| Frequency9 | 3 | 3 | 4 | 7 | 8 | 7 | 7 | 2 | 5 | 3 | 2 | 6 |

Please note that frequencies 0, 1 and 2 were manually removed in the example above.

SETTINGS – CONFIGURATION FILE SETUP

This page provides non editable information showing the native format of entire VoIP Configuration parameter settings. The **settings** format is exactly what is used in the configuration file. The configuration file is found in the TFTP server.

The filename for the configuration server is **<MAC_Address>.cfg**. The configuration file is saved in the folder **/Config** in the TFTP sever.

There are three ways to edit the configuration file or make changes to the **settings** page:

1. Using the VoIP Configuration interface to make changes. Each page of the HTTP web interface is a template for which the user can customise settings in the configuration file.
2. Retrieving the relevant configuration file from the TFTP and modify and enter new changes. This should be done with an expert network administrator.
3. Navigate to the settings page of the VoIP Configuration interface > copy the contents of settings > save them to any standard text editor e.g. notepad > modify the relevant contents, make sure you keep the formatting intact > Save the file as **<Enter_MAC_Address_of_RFP>.cfg** > upload it into the relevant TFTP server.

An example of contents of settings is as follows:

```
~RELEASE=UMBER_FP_V0054
%GMT_TIME_ZONE%:16
%COUNTRY_VARIANT_ID%:18
%FWU_POLLING_ENABLE%:0
%FWU_POLLING_MODE%:0
%FWU_POLLING_PERIOD%:86400
%FWU_POLLING_TIME_HH%:3
%FWU_POLLING_TIME_MM%:0
%DST_ENABLE%:2
%DST_FIXED_DAY_ENABLE%:0
%DST_START_MONTH%:3
%DST_START_DATE%:1
. . . .
. . . .
```

SYS LOG

This page shows live feed of system level messages of the current base station. The messages the administrator see here depends on what is configured at the Management settings. The Debug logs can show only **Boot Log** or **Everything** that is all system logs including boot logs.

The Debug log is saved in the file format **<Time_Stamp>b.log** in a relevant location in the TFTP server as specified in the upload script.

A sample of debug logs follows:

```
0101000013 [N](01):DHCP Enabled
0101000013 [N](01):IP Address: 192.168.10.101
0101000013 [N](01):Gateway Address: 192.168.10.254
0101000013 [N](01):Subnet Mask: 255.255.255.0
0101000013 [N](01):TFTP boot server not set by DHCP. Using Static.
0101000013 [N](01):DHCP Discover completed
0101000013 [N](01):Time Server: 192.168.10.11
0101000013 [N](01):Boot server: 10.10.104.63 path: Config/ Type:
TFTP
0101000013 [N](01):RemCfg: Download request of
Config/00087b077cd9.cfg from 10.10.104.63 using TFTP
0101000014 [N](01):accept called from task 7
0101000014 [N](01):TrelAccept success [4]. Listening on port 10010
0101000019 [N](01):RemCfg: Download request of
Config/00087b077cd9.cfg from 10.10.104.63 using TFTP
0101000019 [W](01):Load of Config/00087b077cd9.cfg from 10.10.104.63
failed
```

To dump the logs, simply copy and paste the full contents.

SIP LOGS

This page shows SIP server related messages that are logged during the operation of the system. The full native format of SIP logs is saved in the TFTP server as

<MAC_Address><Time_Stamp>SIP.log

These logs are saved in 2 blocks of 17Kbytes. When a specific SIP log is fully dumped to one block, the next SIP logs are dumped to the other blocks. An example of SIP logs is shown below:

```
.....
Sent to udp:192.168.10.10:5080 at 12/11/2010 11:56:42 (791 bytes)
REGISTER sip:192.168.10.10:5080 SIP/2.0
Via: SIP/2.0/UDP
192.168.10.101:5063;branch=z9hG4bKrlga4nkuhimpnj4.qx
Max-Forwards: 70
From: <sip:Ext003@192.168.10.10:5080>;tag=3o5l314
To: <sip:Ext003@192.168.10.10:5080>
Call-ID: p9st.zzrfff66.ah8
CSeq: 6562 REGISTER
Contact: <sip:Ext003@192.168.10.101:5063>
Allow: INVITE, CANCEL, BYE, ACK, REGISTER, OPTIONS, REFER,
SUBSCRIBE, NOTIFY, MESSAGE, INFO, PRACK
Expires: 120
User-Agent: Generic-DPV-001-A-XX(Generic_SIPEXT2MLUA_v1)
Content-Type: application/X-Generic_SIPEXT2MLv1
Content-Length: 251
.....
```

To dump the log simply copy and page the full contents.

FIRMWARE UPGRADES

DOWNLOAD FIRMWARE FILES

- STEP 1** Log into Mitel Connect (<https://connect.mitel.com/connect/>).
- STEP 2** Access Mitel Online.
- STEP 3** Under **Support**, click **Software Downloads**, and then click **IP DECT**.
- STEP 4** Download the ZIP file of the firmware files.


UPGRADE THE FIRMWARE

This procedure describes how to upgrade the base station and handset firmware. You can also use this procedure to upgrade the repeater firmware.



Note: In the following example, the TFTP server is running on a PC.

- STEP 1** Create a folder on the tftp server for the firmware files. For example:
 - C:\TFTP\9430\
 - C:\TFTP\8430\
- STEP 2** Copy the firmware files into their respective folders. The 9430 folder is for the base station and the 8430 folder is for the handset:
 - C:\TFTP\9430\9430_v0355_b0004.fwu
 - C:\TFTP\8430\8430_v0355_b0004.fwu
- STEP 3** In the TFTP server settings, enter C:\TFTP in the Base Directory field and change the Timeout to 20 seconds.



STEP 3 Login to the Mitel 112 DECT base station management interface.

STEP 4 Click **Firmware Update**.

- In the Firmware update server address field, enter the IP address of the TFTP server.
- Leave the Firmware path blank.
- Leave the Image path field blank.
- Set the Required version field to the last three digits of the file version. For example, for firmware file 9430_v0355_b0004.fwu, enter 355.
- Set the Required branch field. For example, for firmware file 9430_v0355_b0004.fwu, enter 004.


STEP 5 Click **Save/Start Update**.

STEP 6 Monitor the log on the TFTP server to confirm that the file transfer is taking place. The Base LED starts flashing (orange, then red, then solid green). The Base station performs its upgrade first. Then, the phone firmware is transferred and the handset is upgraded.

VERIFICATION OF FIRMWARE UPGRADE

The firmware upgrade is confirmed by the FWU Progress status in the second and first right column on the handset extension list or repeater list. The “FWU info” column contains the software version and the “FWU Progress” column contains the status. In case status is “Complete”, the unit is firmware upgraded.

Alternatively the handset firmware can be verified from the Handset **Menu** by navigate to **Settings** > Scroll down to **Status** this will list information regarding Base station and Handset firmware versions.



FUNCTIONALITY OVERVIEW

So far we have set up our system. Next, in this chapter we list what features and functionalities are available in the system. The System supports all traditional and advanced features of most telephony networks. In addition, 3rd party components handle features like voice mail, call forward, conference calls, etc. A brief description of VOIP network functionalities are:

- **Outgoing/incoming voice call management:** The System can provide multiple priority user classes. Further, up to 3 repeaters can be linked to a Base-station.
- **Internal handover:** User locations are reported to SIP Server in order to provide differentiated services and tariff management. Within a DECT traffic area, established calls can seamlessly be handover between Base-station and repeaters using connection handover procedures.
- **Security:** The RTX System also supports robust security functionalities for Base-station. Most security¹ functionality is intrinsically woven into the VOIP network structure so that network connections can be encrypted and terminal authentication can be performed.
- **Hospitality:** For Hotel/Motel environments you can apply the following system behaviors by enabling the **Hotel Mode** setting in **Management Settings** page of the of the IP DECT web configuration interface:
 - Black out the handset display when placed in cradle (after 65 seconds)
 - Protect the handset **Settings** menu (changes default handset PIN from 0000 to 9351 and the PIN is required to access the **Settings** menu)
 - Enable silent upgrades and resets
 - Disable call logging
 - Prevent phonebook modification.

BASE STATION INTERFACES

Interfaces

| | |
|-------|--|
| Power | Input: 100-240 VAC 50-60Hz (90 – 265 VAC) Output Nom: 5VDC 1000mA Type: Switch mode single or multi-plug solution Plugs: UK, EU, US and AUS |
|-------|--|

| | |
|---------------|--|
| LAN Interface | Standard : 10BASE-T(IEEE 802.3 100Mbps) Connector: RJ45 8/8 |
|---------------|--|

Keys

1: Reset key, Page and Default

LED indicator

One Status LED (multicolour, red, green, orange)

¹ With active security 4 channels is supported

RF

| | |
|-----------------|--|
| Frequency Bands | 1880 – 1900 MHz (EMEA) 1910 – 1930 MHz (Latam) 1920 – 1930 MHz (USA) Factory setting which can't be modified after production |
|-----------------|--|

| | |
|--------------|--|
| Output Power | 250 mW or 140mW depending on country version |
|--------------|--|

| | |
|---------|----------------------------|
| Antenna | Two antennas for diversity |
|---------|----------------------------|

Software upgrade

| | |
|--------------|--|
| Downloadable | Remote firmware update using HTTP, HTTPS or TFTP |
|--------------|--|

Temperatures

| | |
|-----------|-------------|
| Operation | 0°C to 40°C |
|-----------|-------------|

SOFTWARE FEATURES

CODEC's

| | |
|-------------------------|---|
| G.711 PCM A-law & U-law | Yes |
| G.722 | Yes |
| G.726 | Yes |
| G.729 | A/AB (including VAD), max 4 coders G729 licence not included |

SIP

| | |
|---------|---|
| RFC2327 | SDP: Session Description Protocol |
| RFC2396 | Uniform Resource Identifiers (URI): Generic Syntax |
| RFC2833 | In-Band DTMF/Out of band DTMF support |
| RFC2976 | The SIP INFO method |
| RFC3261 | SIP 2.0 |
| RFC3262 | Reliability of Provisional Responses in the Session Initiation Protocol (PRACK) |
| RFC3263 | Locating SIP Servers (DNS SRV, redundant server support) |
| RFC3264 | Offer/Answer Model with SDP |
| RFC3265 | Specific Event Notification |
| RFC3326 | The Reason Header Field for the Session Initiation Protocol |
| RFC3311 | The Session Initiation Protocol UPDATE Method |
| RFC3325 | P-Asserted Identity |

| | |
|--------------------|--|
| RFC3326 | The Reason Header Field for the Session Initiation Protocol (SIP) |
| RFC3489 | STUN |
| RFC3515 | REFER: Call Transfer |
| RFC3550 | RTP: A Transport Protocol for Real-Time Application |
| RFC3581 | Rport |
| RFC3842 | Message Waiting Indication |
| RFC3891 | Replace header support |
| RFC3892 | The Session Initiation Protocol (SIP) Referred-By Mechanism |
| RFC3960 | Early Media and Ringing Tone Generation in the Session Initiation Protocol (SIP) |
| RFC4475 | Session Initiation Protocol (SIP) Torture Test Messages |
| SIPS | Secure SIP |
| In-band DTMF | No |
| SRTP | Yes, packet authentication will limit the number of calls to 4 |
| SIP registrations | max 20 |
| RTP streams | max 10 |
| SIP transport | UDP, TCP or TLS |
| Web server | |
| | Embedded web server, accessed using HTTP |
| Other features | |
| IP quality | Warning – Network outage, VoIP service outage |
| Jitter buffer | Yes, adaptive |
| Automatic DST | Yes |
| Tone Scheme | Country Depend Tone Scheme |
| Provisioning | Yes |
| Re-direct server | Yes |
| SIP configuration | Yes, from web page or configuration file |
| Call groups | Yes |
| IP features | |
| IPv4 | Yes |
| IPv6 | Hardware ready, software not included |
| TCP/IP/UDP | Yes |
| DHCP Support | Yes |

| | |
|-----------------------|---|
| DHCP option | 66, 120 |
| Static IP | Yes |
| DNS srv | Yes |
| VLAN | Yes, 802.1p/q |
| Quality of service | Type of Service (ToS) including DiffServ Tagging, and QoS per IEEE 802.1p/q |
| TLS | Yes, 1.0 |
| Certificates | Yes, X.509 (certificate not included) |
| TFTP | Yes, for firmware and configuration file download |
| HTTP server | Yes |
| HTTP client | Yes, for firmware and configuration file download |
| HTTPS | Yes, for firmware and configuration file download |
| SNTP | Yes, For internet clock synchronization |
| DECT | |
| DECT handover | Yes, inter-cell handover for repeater support |
| CAT-IQ v1.0 | HD audio or NB audio support |
| Repeater support | Yes |
| Intercom | No |
| DECT encryption | Yes |
| DECT Authentication | Yes |
| Group TPUI support | Yes, for call groups |
| GAP compliant | No |
| CAT-IQ compliant | No |
| Handset registrations | 20 |

CALL FEATURES

| | |
|----------------------------|---|
| Call supported | 5 simultaneous call supported |
| Simultaneous calls/base | 5 Wideband calls (g.722). 5 narrowband calls (PCMA, PCMU, G.726) or 4 when using G729 |
| Simultaneous calls/handset | 2 |
| Call features | Codec Negotiation |
| | Codec Switching |
| | Missed call notification |

| |
|---|
| Voice message waiting notification |
| Date and Time synchronization |
| Parallel calls |
| Call Hold |
| Call Retrieve |
| Call transfer unannounced |
| Call transfer announced |
| Conference (3PTY) |
| Conference, Network |
| Call Waiting Indication |
| Calling line identity |
| Outgoing call |
| Call Toggle/Swap |
| Incoming call |
| Line identification |
| Multiple Lines |
| Multiple calls |
| Call identification |
| Calling Name Identification Presentation (CNIP) |
| Calling Line Identification Presentation (CLIP) |
| Call Completed Elsewhere |
| Distinctive Ringing |

Central Phone Book:

| | |
|--------|---|
| - LDAP | Yes |
| - XML | Yes, remote or file load from web interface |
| - CSV | Yes, file load through web interface |

DND: Yes

Call Forward: Configurable from base or handset (Not with Call Group active))

| | |
|--------|-----|
| - CFU | Yes |
| - CFNA | Yes |
| - CFB | Yes |

Call groups:

Yes, 1-20 handsets/SIP account

APPENDIX A: BASIC NETWORK SERVER(S) CONFIGURATION

In this chapter we describe how to setup the various server elements in the system.

SERVER SETUP

In the network, the server environment is installed as a centralized system.

The main server types hosted on the network include SIP, DNS/DHCP and HTTP/TFTP Servers. These servers can be hosted both in one or multiple windows and/or Linux Server environment.

Management servers are normally installed to monitor and manage the network in detail. Each Base-station status can be checked. Each Repeater and each Subscriber Terminal can be monitored over the air from a centralized location.

Further, new software can be uploaded to all system elements from the centralized location (typically a TFTP server) on an individual basis. This includes Subscriber Handsets where the latest software is downloaded over the air.

REQUIREMENTS

Regardless of whether or not you will be installing a centrally provisioned system, you must perform basic TCP/IP network setup, such as IP address and subnet mask configuration, to get your organization's phones up and running.

DNS SERVER INSTALLATION/SETUP

Name server is a name server service installed in a server for mapping or resolution of humanly memorable domain names and hostnames into the corresponding numeric Internet Protocol (IP) addresses.

The customer should refer to the platform vendor either windows or Linux vendor for detail step-by-step guide on how to install and configure Domain Name System for internet access. In this section, we briefly describe hints on how to setup DNS behind NAT or Firewall.


Hints on how to Configure DNS behind a Firewall/NAT

Proxy and Network Address Translation (NAT) devices can restrict access to ports. Set the DNS to use UDP port 53 and TCP port 53. For windows Servers, set the RCP option on the DNS Service Management console and configure the RCP to use port 135.

These settings should be enough to resolve some of potential issues that may occur when you configure DNS and firewalls/NAT.

DHCP SERVER SETUP

A DHCP Server allows diskless clients to connect to a network and automatically obtain an IP address. This server is capable of supplying each network client with an IP address, subnet mask, default gateway, an IP address for a WINS server, and an IP address for a DNS server. This is very often used in enterprise networks to reduce configuration efforts. All IP addresses of all computers/routers/bases are stored in a database that resides on a server machine.



The network administrator should contact the relevant vendors for detail information or step-by-step procedure on how to install and setup DHCP process or service on windows/Linux servers. In this section, we will provide some hints of how to resolve potential problems to be encountered you setup DHCP Servers.

DHCP SERVER TROUBLESHOOTING

Windows Server:

1. Clients are unable to obtain an IP address

If a DHCP client does not have a configured IP address; it generally means that the client has not been able to contact a DHCP server. This is either because of a network problem or because the DHCP server is unavailable. If the DHCP server has started and other clients have been able to obtain a valid address, verify that the client has a valid network connection and that all related client hardware devices (including cables and network adapters) are working properly.

2. The DHCP server is unavailable

When a DHCP server does not provide leased addresses to clients, it is often because the DHCP service has failed to start. If this is the case, the server may not have been authorized to operate on the network. If you were previously able to start the DHCP service, but it has since stopped, use Event Viewer to check the system log for any entries that may explain the cause.

Next, restart the DHCP service, click **Start**, click **Run**, type **cmd**, and then press ENTER. Type **net start dhcpserver**, and then press ENTER.

Linux Platform:

Troubleshooting DHCP, check the following:

1. Incorrect settings in the **/etc/dhcpd.conf** file such as not defining the networks for which the DHCP server is responsible;
2. NAT/Firewall rules that block the DHCP **bootp** protocol on UDP ports 67 and 68;
3. Routers failing to forward the **bootp** packets to the DHCP server when the clients reside on a separate network. Always check your **/var/logs/messages** file for dhcpd errors.
4. Finally restart the **dhcpd** service daemon


TFTP SERVER SETUP

There are several TFTP servers in the market place; in this section we describe how to setup a commonly used TFTP Server.


TFTP SERVER SETTINGS

The administrator must configure basic parameters of the TFTP application:

- Specify UDP 69 port – for TFTP incoming requests and TCP 12000 – for remote management of the server. For file transmission the server opens UDP ports with random numbers. In case the option **Enable NAT or firewall support** is activated on the server, the server uses the same port for files transmission and listening to the TFTP incoming requests (UDP 69 port on default).
- Specify the interface bindings, TFTP root directory, port which the TFTP Server will listen, timeout and number of retries, and TFTP options supported by the server.



- Configure the relevant TFTP virtual folder in the server. The TFTP virtual folder is the file folder, visible for TFTP clients under a certain name. You can set security settings separately for every virtual TFTP folder. Next, set rights to access TFTP folders according to the relevant clients.



APPENDIX B: USING BASE WITH VLAN NETWORK

In this chapter we describe how to setup a typical VLAN in the network.

INTRODUCTION


In this chapter, we describe how to setup VLAN to typical network. There are three main stages involved in this procedure:

1. Configure a VLAN Aware Switch to a specific (un)tagged VLAN ID, so the system can process untagged frames forwarded to it.
2. Setup the Time Server (NTP Server) and other relevant network servers.
3. Configure the HTTP server in the Base station to access the features in the PBX or system.

VLAN allows administrators to separate logical network connectivity from physical connectivity analogous to traditional LAN which is limited by its physical connectivity. Normally, users in a LAN belong to a single broadcast domain and communicate with each other at the Data Link Layer or "Layer 2". LANs are segmented into smaller units for each IP subnets and here communication between subnets is possible at the Network Layer or "Layer 3", using IP routers.

A VLAN can be described as a single physical network that can be logically divided into discrete LANs that can operate independently of each other.

An Illustration of using VLANs to create independent broadcast domains across switches is shown below:



The figure above highlights several key differences between traditional LANs and VLANs.

- All switches are interconnected to each other. However, there are three different VLANs or broadcast domains on the network. Physical isolation is not required to define broadcast domains. If the figure was a traditional LAN without VLAN-aware switches, all stations would belong to one broadcast domain.

- All switch ports can communicate with one another at the Data Link Layer, if they become members of the same VLAN.
- The physical location of an end station does not define its LAN boundary.
 1. An end station can be physically moved from one switch port to another without losing its “view of the network”. That is, the set of stations it can communicate with at the Data Link Layer remains the same, provided that its VLAN membership is also migrated from port to port.
 2. By reconfiguring the VLAN membership of the switch port an end station is attached to, you can change the network view of the end station easily, without requiring a physical move from port to port.

BACKBONE/ VLAN AWARE SWITCHES

To implement a VLAN in your network, you must use VLAN-aware switches.

Before we continue, let consider two rules to remember regarding the functioning of a regular LAN switch:

1. When the switch receives a broadcast or multicast frame from a port, it floods (or broadcasts) the frame to all other ports on the switch.
2. When the switch receives a unicast frame, it forwards it only to the port to which it is addressed.

A VLAN-aware switch changes the above two rules as follows:


1. When the switch receives a broadcast or multicast frame from a port, it floods the frame to only those ports that belong to the same VLAN as the frame.
2. When a switch receives a unicast frame, it forwards it to the port to which it is addressed, only if the port belongs to the same VLAN as the frame.
3. A unique number called the VLAN ID identifies each VLAN.

Which VLAN Does a Frame Belong To?

The previous section notes that a frame can belong to a VLAN. The next question is—how is this association made?

- A VLAN-aware switch can make the association based on various attributes of the type of frame, destination of MAC address, IP address, TCP port, Network Layer protocol, and so on.

An illustration of IEEE 802.1Q VLAN tag in Ethernet frame is as follows:



HOW VLAN SWITCH WORK: VLAN TAGGING

VLAN functionality can be implemented via explicit frame tagging by switches and end stations. Network switches and end stations that know about VLANs are said to be VLAN aware. Network switches and end stations that can interpret VLAN tags are said to be VLAN tag aware. VLAN-tag-aware switches and end stations add VLAN tags to standard Ethernet frames—a process called explicit tagging. In explicit tagging, the end station or switch determines the VLAN membership of a frame and inserts a VLAN tag in the frame header (see figure above for VLAN tagging), so that downstream link partners can examine just the tag to determine the VLAN membership.


IMPLEMENTATION CASES

Common types of usage scenarios for VLANs on typical VLAN switches: port-based VLANs, protocol-based VLANs, and IP subnet-based VLANs. Before figuring out which usage scenario suits your needs, you must understand what each type of usage scenario implies.

- **Port-based VLAN:** All frames transmitted by a NIC are tagged using only one VLAN ID. The NIC does not transmit or receive any untagged frames.

All protocols and applications use this virtual interface's virtual PPA to transmit data traffic. Therefore all frames transmitted by that NIC port are tagged with the VLAN ID of that Virtual Interface.

- **Protocol-based VLAN:** The NIC assigns a unique VLAN ID for each Layer 3 protocol (such as IPv4, IPv6, IPX, and so on). Therefore, the VLAN ID of outbound frames is different for each protocol. An inbound frame is dropped if the protocol and VLAN ID do not match.
- **IP subnet-based VLAN:** The NIC assigns a unique VLAN ID for each IP subnet it belongs to. Therefore, the VLAN ID of outbound frames is different for different destination subnets. An inbound frame is dropped if the IP subnet and VLAN ID do not match.



BASE STATION SETUP

After the admin have setup the Backbone switch, next is to configure the Base station via HTTP interface.

- STEP 1** Connect the Base station to a private network via standard Ethernet cable (CAT-5).
- STEP 2** Use one of the two methods to find the base IP
- STEP 3** On the Login page, enter your authenticating credentials (the username and password is admin by default unless it is changed). Click OK button.
- STEP 4** Once you have authenticated, the browser will display front end of the Configuration Interface. The front end will show relevant information of the base station.
- STEP 5** Create the relevant SIP server information in the system. Each service provider/customer should refer SIP server vendor on how to setup SIP servers.

CONFIGURE TIME SERVER

- STEP 6** Navigate to the Time settings and configure it. Scroll on the left column and click on **Time** url link to Open the **Time Settings** Page. Enter the relevant parameters on this page and press the **Save** button.

Mitel SME VoIP

Time Settings

Time PC

Time Server: ca.pool.ntp.org

Allow broadcast NTP:

Refresh time (h): 24

Set timezone by country/region:

Timezone: -5:00

Set DST by country/region:

Daylight Saving Time (DST): Automatic

DST Fixed By Day: Use Month and Day of Week

DST Start Month: March

DST Start Date: 0

DST Start Time: 2

DST Start Day of Week: Sunday

DST Start Day of Week Last in Month: Second First In Month

DST Stop Month: November

DST Stop Date: 0

DST Stop Time: 2

DST Stop Day of Week: Sunday

DST Stop Day of Week Last in Month: First In Month

Save and Reboot Save Cancel

VLAN SETUP: BASE STATION

- STEP 7** Navigate to the **Network** url > On the network page enter the relevant settings in the VLAN section > VLAN Id should be the same as those configured into the backbone.



- Home/Status
- Extensions
- Servers
- Network**
- Management
- Firmware Update
- Time
- Country
- Security
- Central Directory
- Repeaters
- Statistics
- Configuration
- Syslog
- SIP Log
- Logout

Network Settings

IP settings

DHCP/Static IP:

IP Address:

Subnet Mask:

Default Gateway:

DNS (Primary):

DNS (Secondary):

NAT Settings

Enable STUN:

STUN Server:

STUN Bindtime Determine:

STUN Bindtime Guard:

Enable RPORT:

Keep alive time:

VLAN Settings

ID:

User Priority:

SIP/RTP Settings

Use Different SIP Ports:

RTP Collision Detection:

Always reboot on check-sync:

Local SIP port:

SIP ToS/QoS:

RTP port:

RTP port range:

RTP ToS/QoS:

DHCP Options

Plug-n-Play:

APPENDIX C: LOCAL CENTRAL DIRECTORY FILE HANDLING

This appendix the Local Central Directory file format, import and configuration is described.

CENTRAL DIRECTORY CONTACT LIST STRUCTURE

The structure of Contact List is simple. The figure below shows an example of structure of Contact List in Text format and in Xml format. **Contact name must not contain more than 23 characters and contact number must not contain more than 21 digits.**

.csv or .txt

```
File Edit Format View Help
Dennis Iversen,+4596322382
Torsten Krogh Elgaard,2381
Rune Thor Jensen,2445
Maija-Liisa Knudsen,2377
Jesper Jensen,2346
Kristian Kjaer,2447
Gitte Dyhr Petersen,2470
Sukesh Reddy,2749
Morten Fredegod,4726
Annemarie Dahl,2861
Hans Back,2721
Henrik Olsen,2733
Jens Martin Jensen,2782
Kenneth Skiveren,2363
Lars Christensen (RTX),2433
```

.xml

```
File Edit Format View Help
<IPPhoneDirectory>
<DirectoryEntry>
<Name>Mark Ross</Name>
<Telephone>100</Telephone>
<Office>+450123456789</Office>
<Mobile>+451123456789</Mobile>
<Fax>+452123456789</Fax>
</DirectoryEntry>
</IPPhoneDirectory>
```

.txt file limitations:

- Contact name must NOT be longer than 23 characters (name will be truncated)
- Contact name must NOT contain “,”
- Contact number must be limited to 21 digits (entry will be discarded, no warning)
- Contact number digits must be: +0123456789
- Contact number does not support SIP-URI
- Spaces between name section “,” and number section is not supported

CENTRAL DIRECTORY CONTACT LIST FILENAME FORMAT

The Contact list is saved as file format: **.txt .csv** or **.xml**

IMPORT CONTACT LIST TO CENTRAL DIRECTORY

On the **Central Directory** page, the admin should click on **Browse** button and the **Choose File to Load** dialog window will be shown.

On the **Choose File to Upload** dialog window, navigate to the directory or folder that contains the right file to be imported to the base station > Click on **Open** button.

Mitel SME VoIP

Home/Status
Extensions
Servers
Network
Management
Firmware Update
Time
Country
Security
Central Directory
Repeaters

Management Settings

Base Station Name:

Settings

Management Transfer Protocol:

HTTP Management upload script:

User Name:

HTTP Management password:

Enable Automatic Prefix:

Set Maximum Digits of Internal Numbers:

Set Prefix for Outgoing Calls:

Syslog/SIP Log

Upload of SIP Log:


SIP Log Server Address:

Syslog Level:

Syslog Server IP Address:

Syslog Server Port:

Next, click on the **Load** button. This will import the contents of contacts in the selected file into the relevant Base station.



The figure below shows the import procedure is in process.



The parameters are successfully saved
You will be redirected after 3 seconds

CENTRAL DIRECTORY USING SERVER

Alternative way to import a Contact List is to get it from a server. Click Management to access the Management Settings page, then select the protocol of your server (TFTP/HTTP/HTTPS) in Management Transfer Protocol, then save the setting by clicking Save.

Mitel SME VoIP

Management Settings

Base Station Name:

Settings

Management Transfer Protocol:

HTTP Management upload script:

User Name:

HTTP Management password:

Enable Automatic Prefix:

Set Maximum Digits of Internal Numbers:

Set Prefix for Outgoing Calls:

Syslog/SIP Log

Upload of SIP Log:

SIP Log Server Address:

Syslog Level:

Syslog Server IP Address:

Syslog Server Port:

Go back to Central Directory page and enter Server IP address (inclusive the path in the end of the address) and Filename of the contact list, then save the setting by clicking Save. (See example below).

Mitel SME VoIP

Central Directory

Location:

Server:

Filename:

Phonebook reload interval (s):

Import Central Directory:

Filename:

Then reboot the Base station to ensure that the changes take effect.

VERIFICATION OF CONTACT LIST IMPORT TO CENTRAL DIRECTORY

On the Handset, navigate to Central Directory. The contact list should be populated with the list of contacts that you uploaded to the base station.

